

Refrigerator eligible models^

Brand name	Model number	Type
ABL	AREF18**	Top Freezer
ABL	AREF18B	Top Freezer
ABL	AREF18S	Top Freezer
ABL	AREF18W	Top Freezer
APPLIANCE BASICS	HD676REWNSS	Bottom Freezer
APPLIANCE BASICS	HD774FWSS	Top Freezer
ARTT	ATBM19	Bottom Freezer
ARTT	ATBM19	Bottom Freezer
AVALLON	AWC243TDZLHA	Cooler
AVALLON	AWC243TDZRHA	Cooler
AVALLON	AWC243TSZLH	Cooler
AVALLON	AWC243TSZRH	Cooler
AVG	ETB72U6L	Bottom Freezer
AVG	TB1112HY	Bottom Freezer
AVG	ARBM150SE	Bottom Freezer
AVG	ARBM171DSE	Bottom Freezer
AVG	ARBM172BSE	Bottom Freezer
AVG	ARBM172SE	Bottom Freezer
AVG	ARBM172WE	Bottom Freezer
AVG	Compressor options:C127	Bottom Freezer
AVG	RDTM181SE	Top Freezer
AVG	RDTM181WE	Top Freezer
AVIVA	ARBM115SB	Bottom Freezer
AVIVA	ARBM177SE	Bottom Freezer
AVIVA	ARBM184FSE2	Bottom Freezer
AVIVA	ARBM184FSE3	Bottom Freezer
AVIVA	ARBM184FSE3	Bottom Freezer
AVIVA	ARBM187**	Bottom Freezer
AVIVA	ARBM188*E4	Bottom Freezer
AVIVA	ARBM188*E4	Bottom Freezer
AVIVA	ARTM142**	Top Freezer
Absocold	ARD1033FB21R/L	Top Freezer
Absocold	ARD1033FS21R/L	Top Freezer
Absocold	ARD1033FW21R/L	Top Freezer
Alpha PAR RD	RDBM191**	Bottom Freezer
Alpha PAR RD	RDTM116WE	Top Freezer
Amana	ART348FFF***	Top Freezer
Amana	ART348FFF***	Top Freezer
Arctic Wind	ATM**212E	Top Freezer
Arctic Wind	AUFSS210ETH-LK	Freezerless and Single Door
Arctic Wind	AUFW210ETH-LK	Freezerless and Single Door
Asko	WCN311942G	

Avanti	AFS157LSS	Side-by-Side
Avanti	AV1081VFK0W	Freezerless and Single Door
Avanti	AV160VFK0W	Freezerless and Single Door
Avanti	AV2121VFB0W	Freezerless and Single Door
Avanti	AVFF18DLJ#**	Top Freezer
Avanti	AVFF21DLJM#**	Top Freezer
Avanti	AVFF24DLJM#**	Top Freezer
Avanti	FF10B***	Top Freezer
Avanti	FF116B0W	Top Freezer
Avanti	FF14D0W-4	Top Freezer
Avanti	FF14D3S-4	Top Freezer
Avanti	FF14V0W	Top Freezer
Avanti	FF14V1B	Top Freezer
Avanti	FF14V3S	Top Freezer
Avanti	FF18H**	Top Freezer
Avanti	FF18H0W	Top Freezer
Avanti	FF18H3S	Top Freezer
Avanti	FFFDD18L3S	Bottom Freezer
Avanti	FFFDS175L3S	Bottom Freezer
Avanti	VF108K0W	Freezerless and Single Door
BERTAZZONII	RBM24F4FXNV	Bottom Freezer
BLACK DECKER	BR1210HB	Top Freezer
BLACK DECKER	BR1210HS	Top Freezer
BLACK DECKER	BR1210HW	Top Freezer
BLACK DECKER	BR1460HB	Top Freezer
BLACK DECKER	BR1460HS	Top Freezer
BLACK DECKER	BR1460HW	Top Freezer
BLACK DECKER	BR1810HB	Top Freezer
BLACK DECKER	BR1810HIMB	Top Freezer
BLACK DECKER	BR1810HIMS	Top Freezer
BLACK DECKER	BR1810HIMW	Top Freezer
BLACK DECKER	BR1810HS	Top Freezer
BLACK DECKER	BR1810HW	Top Freezer
BLACK DECKER	BR2010JB	Top Freezer
BLACK DECKER	BR2010JIMB	Top Freezer
BLACK DECKER	BR2010JIMS	Top Freezer
BLACK DECKER	BR2010JIMW	Top Freezer
BLACK DECKER	BR2010JS	Top Freezer
BLACK DECKER	BR2010JW	Top Freezer
BLACK DECKER	BR2400JB	Top Freezer
BLACK DECKER	BR2400JIMB	Top Freezer
BLACK DECKER	BR2400JIMS	Top Freezer
BLACK DECKER	BR2400JIMW	Top Freezer
BLACK DECKER	BR2400JS	Top Freezer
BLACK DECKER	BR2400JW	Top Freezer
BLACK+DECKER	BDA12GLAB	Top Freezer
BLACK+DECKER	BDA12GLAS	Top Freezer
BLACK+DECKER	BDA12GLAW	Top Freezer
BLACK+DECKER	BRF1600GIMB	Bottom Freezer
BLACK+DECKER	BRF1600GIMS	Bottom Freezer
BLACK+DECKER	BRF1600GIMW	Bottom Freezer
BLACK+DECKER	BRF1800GIMB	Bottom Freezer
BLACK+DECKER	BRF1800GIMS	Bottom Freezer

BLACK+DECKER	BRF1800GIMW	Bottom Freezer
BLACK+DECKER	BUC1100XB	Freezerless and Single Door
BLACK+DECKER	BUC1100XS	Freezerless and Single Door
BLACK+DECKER	BUC1100XW	Freezerless and Single Door
BLACK+DECKER	BUC1400XB	Freezerless and Single Door
BLACK+DECKER	BUC1400XS	Freezerless and Single Door
BLACK+DECKER	BUC1400XW	Freezerless and Single Door
BLACK+DECKER	BUC1700XB	Freezerless and Single Door
BLACK+DECKER	BUC1700XS	Freezerless and Single Door
BLACK+DECKER	BUC1700XW	Freezerless and Single Door
BLACK+DECKER	BUC2120M*	Freezerless and Single Door
BLUE STAR	BBB36*3	Bottom Freezer
BLUE STAR	FBFD361	Bottom Freezer
BRAMA	VFA090CY1	Bottom Freezer
BRAMA	BR2660IFDRSS	Bottom Freezer
BRAMA	with 2 compressor options:	Bottom Freezer
Beko	BBBF2410	Bottom Freezer
Beko	BBBF2410IM2	Bottom Freezer
Beko	BBBF2813IM	Bottom Freezer
Beko	BBBF3019IMWESS	Bottom Freezer
Beko	BBBF3019WE	Bottom Freezer
Beko	BFBD30216SS	Bottom Freezer
Beko	BFBD30216SSIM	Bottom Freezer
Beko	BFBD30216SSIML	Bottom Freezer
Beko	BFBD30216SSL	Bottom Freezer
Beko	BFBF2412SS	Bottom Freezer
Beko	BFBF2414SS	Bottom Freezer
Beko	BFBF2414SSIM	Bottom Freezer
Beko	BFBF2414WH	Bottom Freezer
Beko	BFBF2414WHIM	Bottom Freezer
Beko	BFBF2815SS	Bottom Freezer
Beko	BFBF2815SSIM	Bottom Freezer
Beko	BFBF30116SS	Bottom Freezer
Beko	BFBF30116SSIM	Bottom Freezer
Beko	BFBF30116WHIM	Bottom Freezer
Beko	BFBF30216SS	Bottom Freezer
Beko	BFBF30216SSIM	Bottom Freezer
Beko	BFBF30216SSIML	Bottom Freezer
Beko	BFBF30216SSL	Bottom Freezer
Beko	BFFD30216SSIM	Bottom Freezer
Beko	BFFD30216SSIMX	Bottom Freezer
Beko	BFFD3614ZSS	Bottom Freezer
Beko	BFFD3614ZSS2	Bottom Freezer
Beko	BFFD3624XSS	Bottom Freezer
Beko	BFFD3624ZSS2	Bottom Freezer
Beko	BFFD3626SS	Bottom Freezer
Beko	BFFD3626SS	Bottom Freezer
Beko	BFSB3612XSS	Side-by-Side
Beko	BFTF2716BK	Top Freezer
Beko	BFTF2716SS	Top Freezer
Beko	BFTF2716WH	Top Freezer
Beko	Manufacturers Basic Model	Bottom Freezer
Beko & Blomberg	K60340N	Bottom Freezer

Bertazzoni	REF24BMBIPNV	Bottom Freezer
Bertazzoni	REF24BMBPNB	Bottom Freezer
Bertazzoni	REF24BMFIXNV	Bottom Freezer
Bertazzoni	REF24BMFXNV	Bottom Freezer
Bertazzoni	REF24PR	Bottom Freezer
Bertazzoni	REF24RCBPNV	Freezerless and Single Door
Bertazzoni	REF28BMBIPNV	Bottom Freezer
Bertazzoni	REF30BMBIPLT	Bottom Freezer
Bertazzoni	REF30BMBIPRT	Bottom Freezer
Bertazzoni	REF30BMBIXLT	Bottom Freezer
Bertazzoni	REF30BMBIXRT	Bottom Freezer
Bertazzoni	REF30BMBPNB	Bottom Freezer
Bertazzoni	REF30BMBZPNV	Bottom Freezer
Bertazzoni	REF30RCBPNV	Freezerless and Single Door
Bertazzoni	REF31BMFIXNV	Bottom Freezer
Bertazzoni	REF31BMFXNV	Bottom Freezer
Bertazzoni	REF36BMBIPLT	Bottom Freezer
Bertazzoni	REF36BMBIPRT	Bottom Freezer
Bertazzoni	REF36BMBIXLT	Bottom Freezer
Bertazzoni	REF36BMBIXRT	Bottom Freezer
Bertazzoni	REF36FDBZPNV/24	Bottom Freezer
Bertazzoni	REF36FDFIXN*	Bottom Freezer
Bertazzoni	REF36FDFIXNB	Bottom Freezer
Bertazzoni	REF36FDFIXNV	Bottom Freezer
Bertazzoni	REF36FDFZXNT	Bottom Freezer
Bevoi	BVIREF18*	Top Freezer
Bevoi	BVIREF18W	Top Freezer
Bevoi	BVIREF18W	Top Freezer
Bevoi	Ice maker ready product(with	Top Freezer
Bevoi	Ice maker ready	Top Freezer
Blomberg	7295745710	Bottom Freezer
Blomberg	BRFB1044SS	Bottom Freezer
Blomberg	BRFB1044WH	Bottom Freezer
Blomberg	BRFB1045SS	Bottom Freezer
Blomberg	BRFB1045WH	Bottom Freezer
Blomberg	BRFB1046SS	Bottom Freezer
Blomberg	BRFB1051FFBI2	Bottom Freezer
Blomberg	BRFB1052FFBI2	Bottom Freezer
Blomberg	BRFB1312FBI	Bottom Freezer
Blomberg	BRFB1322FBI	Bottom Freezer
Blomberg	BRFB1532SS	Bottom Freezer
Blomberg	BRFB1542SS	Bottom Freezer
Blomberg	BRFB1900FBI	Bottom Freezer
Blomberg	BRFB1900FBI	Bottom Freezer
Blomberg	BRFB21612SS	Bottom Freezer
Blomberg	BRFB21622SS	Bottom Freezer
Blomberg	BRFD21612SS	Bottom Freezer
Blomberg	BRFD21622SS	Bottom Freezer
Blomberg	BRFD2230XSS	Bottom Freezer
Blomberg	BRFD2234XSS	Bottom Freezer
Blomberg	K76540NEBU	Bottom Freezer
Blomberg	K76540NEBU	Bottom Freezer
Blomberg, beko	K76540NEBWU	Bottom Freezer

Bosch	B09IB91NS*	Bottom Freezer
Bosch	B10CB80NVB	Bottom Freezer
Bosch	B10CB80NVS	Bottom Freezer
Bosch	B10CB80NVW/01	Bottom Freezer
Bosch	B10CB81NV*	Bottom Freezer
Bosch	B11CB50SSS/01	Bottom Freezer
Bosch	B11CB81SSS/01	Bottom Freezer
Bosch	B20CS30SNS	Side-by-Side
Bosch	B24CB50ESS	Bottom Freezer
Bosch	B24CB80ES*	Bottom Freezer
Bosch	B26FT50SNS	Bottom Freezer
Bosch	B30BB130SS	Bottom Freezer
Bosch	B30BB930SS	Bottom Freezer
Bosch	B30BB935SS	Bottom Freezer
Bosch	B30IB100SP	Bottom Freezer
Bosch	B30IB900SP	Bottom Freezer
Bosch	B30IB905SP	Bottom Freezer
Bosch	B30IR900SP	Freezerless and Single Door
Bosch	B30IR905SP	Freezerless and Single Door
Bosch	B36BT130NS	Bottom Freezer
Bosch	B36BT930NS	Bottom Freezer
Bosch	B36BT935NS	Bottom Freezer
Bosch	B36CD10EN*	Bottom Freezer
Bosch	B36CD30EN*	Bottom Freezer
Bosch	B36CD50SN*	Bottom Freezer
Bosch	B36CD51SN*	Bottom Freezer
Bosch	B36CD52SN*	Bottom Freezer
Bosch	B36CD80EN*	Bottom Freezer
Bosch	B36CL80EN*	Bottom Freezer
Bosch	B36CL80SN*	Bottom Freezer
Bosch	B36CL81EN*	Bottom Freezer
Bosch	B36CT80SN*	Bottom Freezer
Bosch	B36CT81EN*	Bottom Freezer
Bosch	B36CT81SN*	Bottom Freezer
Bosch	B36CT82EN*	Bottom Freezer
Bosch	B36CT82SN*	Bottom Freezer
Bosch	B36FD10EN*	Bottom Freezer
Bosch	B36FD30EN*	Bottom Freezer
Bosch	B36FD31EN*	Bottom Freezer
Bosch	B36FD50SN*	Bottom Freezer
Bosch	B36FD51SN*	Bottom Freezer
Bosch	B36IT100NP	Bottom Freezer
Bosch	B36IT900NP	Bottom Freezer
Bosch	B36IT905NP	Bottom Freezer
Brigade	CFBI7360****	Bottom Freezer
Brigade	CMVBI7360****	Bottom Freezer
Brigade	CVBI7360****	Bottom Freezer
CHIONE	CTM12SH	Top Freezer
COSMO	COS-FDR223GWSS	Bottom Freezer
COSMO	COS-FDR225RHSS	Bottom Freezer
COSMO	COS-FDR225RHSS-G	Bottom Freezer
COSMO	COS-RFFV183GHS	Bottom Freezer
COSMO	COS-RFFV183RS	Bottom Freezer

COSMO	COS-RFFV283GHBK	Bottom Freezer
COSMO	COS-RFFV283GHSS	Bottom Freezer
COSMO	COS-RFFV283RBK	Bottom Freezer
COSMO	COS-RFFV283RSS	Bottom Freezer
CTM	XFRBI1821-30**	Freezerless and Single Door
CTM	YFRBI1821-30**	Freezerless and Single Door
CTM	ZFRBI1821-30**	Freezerless and Single Door
Cafe	CAE28DM*T***	Bottom Freezer
Cafe	CFE28TP*M***	Bottom Freezer
Cafe	CFE28UP*M***	Bottom Freezer
Cafe	CGE29DM*T***	Bottom Freezer
Cafe	CGE29DP*T***	Bottom Freezer
Cafe	CHE23DM*W***	Bottom Freezer
Cafe	CJE23DM*W***	Bottom Freezer
Cafe	CJE23DP*W***	Bottom Freezer
Cafe	CVE28DM*NB**	Bottom Freezer
Cafe	CVE28DM*NC**	Bottom Freezer
Cafe	CVE28DM*NE**	Bottom Freezer
Cafe	CVE28DM*NF**	Bottom Freezer
Cafe	CVE28DM*NG**	Bottom Freezer
Cafe	CVE28DP*NB**	Bottom Freezer
Cafe	CVE28DP*NC**	Bottom Freezer
Cafe	CVE28DP*ND**	Bottom Freezer
Cafe	CVE28DP*NE**	Bottom Freezer
Cafe	CVE28DP*NF**	Bottom Freezer
Cafe	CVE28DP*NG**	Bottom Freezer
Cafe	CVE28DP*NH**	Bottom Freezer
Cafe	CVE28DP*NI**	Bottom Freezer
Cafe	CVE28DP*NJ**	Bottom Freezer
Cafe	CWE19SP*N***	Bottom Freezer
Cafe	CWE23SP*M***	Bottom Freezer
Cafe	CXE22DM*P***	Bottom Freezer
Cafe	CXE22DP*P***	Bottom Freezer
Cafe	CYE22TP*M***	Bottom Freezer
Cafe	CYE22UP*M***	Bottom Freezer
Café	CQE28DM*N***	Bottom Freezer
Café	CVE28DM*ND**	Bottom Freezer
Commercial Cool	CCR1800GB	Bottom Freezer
Commercial Cool	CCR1800GIMB	Bottom Freezer
Commercial Cool	CCR1800GIMS	Bottom Freezer
Commercial Cool	CCR1800GIMW	Bottom Freezer
Commercial Cool	CCR1800GS	Bottom Freezer
Commercial Cool	CCR1800GW	Bottom Freezer
Commercial Cool	CCR2000GB	Bottom Freezer
Commercial Cool	CCR2000GIMB	Bottom Freezer
Commercial Cool	CCR2000GIMS	Bottom Freezer
Commercial Cool	CCR2000GIMW	Bottom Freezer
Commercial Cool	CCR2000GS	Bottom Freezer
Commercial Cool	CCR2000GW	Bottom Freezer
Commercial Cool	CCUC1110GB	Freezerless and Single Door
Commercial Cool	CCUC1110GS	Freezerless and Single Door
Commercial Cool	CCUC1110GW	Freezerless and Single Door
Commercial Cool	CCUC1640GB	Freezerless and Single Door

Commercial Cool	CCUC1640GS	Freezerless and Single Door
Commercial Cool	CCUC1640GW	Freezerless and Single Door
Conserv	MDRF1010ESE	Top Freezer
Conserv	MDRF376****	Bottom Freezer
Conserv	MDRF376-1150	Top Freezer
Conserv	RF 1820 FD	Bottom Freezer
Conserv	RF 331-120 (**)	Bottom Freezer
Conserv	TMRI 180S	Top Freezer
Conserv	TMRI 210S	Top Freezer
Conservator	GRHS1762T*	Top Freezer
Conservator	GRMH141A*	Top Freezer
Conservator	GRMH141B*	Top Freezer
Conservator	GRMH183**	Top Freezer
Conservator	GRMH183U*	Top Freezer
Conservator	GRMH185A*	Top Freezer
Conservator	VNRV143AD	Top Freezer
Conservator	VNRV143AW	Top Freezer
Continental	CE-FRF172	Bottom Freezer
Continental Electric	CE-FRF192	Bottom Freezer
Continental;Professional Series	CE-TRF241	Top Freezer
Continental;Professional Series	CE-TRF242	Top Freezer
Continental;Professional Series	CE-TRF248	Top Freezer
Continental;Professional Series	CE-TRF249	Top Freezer
Continental;Professional Series	PS-TRF241	Top Freezer
Continental;Professional Series	PS-TRF242	Top Freezer
Continental;Professional Series	PS-TRF248	Top Freezer
Continental;Professional Series	PS-TRF249	Top Freezer
Criterion	18TMF-B	Top Freezer
Criterion	18TMF-SS	Top Freezer
Criterion	18TMF-W	Top Freezer
Criterion	453-8143	Top Freezer
Criterion	453-8144	Top Freezer
Criterion	453-8145	Top Freezer
Criterion	463-1202	Bottom Freezer
Criterion	463-1208	Bottom Freezer
Criterion	463-1209	Bottom Freezer
Criterion	CBMR187M4*	Bottom Freezer
Criterion	CBMR187M4*	Bottom Freezer
Criterion	CFDR225M3S	Bottom Freezer
Criterion	CFDR286M4S	Bottom Freezer
Criterion	CFRR211P1B	Bottom Freezer
Criterion	CFRR211P1S	Bottom Freezer
Criterion	CFRR211P1W	Bottom Freezer
Criterion	CTMR101C1*	Top Freezer
Criterion	CTMR142C1B	Top Freezer
Criterion	CTMR142C1S	Top Freezer
Criterion	CTMR142C1W	Top Freezer
Criterion	CTMR142M1*	Top Freezer
Criterion	CTMR205M1*	Top Freezer
Criterion	CUF21C1W	Freezerless and Single Door
Crosley	CBMH1873**	Bottom Freezer

Crosley	CBMH1873**	Bottom Freezer
Crosley	CBMH1873A*	Bottom Freezer
Crosley	CFDMH1834AB	Bottom Freezer
Crosley	CFDMH1834AB	Bottom Freezer
Crosley	CFDMH1834AS	Bottom Freezer
Crosley	CFDMH1834AS	Bottom Freezer
Crosley	CFDMH1834AW	Bottom Freezer
Crosley	CFDMH1834AW	Bottom Freezer
Crosley	CFDMH2257AS	Bottom Freezer
Crosley	CFDNH2216AS	Bottom Freezer
Crosley	CFDNH2218AS	Bottom Freezer
Crosley	CFEH2868A*	Bottom Freezer
Crosley	CFEH2868A*	Bottom Freezer
Crosley	CRHS12SS-LH	Top Freezer
Crosley	CRHS12SW-LH	Top Freezer
Crosley	CRM101A*	Top Freezer
Crosley	CRMH203A*	Top Freezer
Crosley	CRSEH237A*	Side-by-Side
Crosley	CRSEH237A*	Side-by-Side
Crosley	CRSEH237A*	Side-by-Side
Crosley	CRSEH267A*	Side-by-Side
Crosley	CRSEH267A*	Side-by-Side
Crosley	CRSEH267A*	Side-by-Side
Crosley	XFE26JSM****	Bottom Freezer
Crosley	XNE25JGK****	Bottom Freezer
Crosley	XNE25JSK****	Bottom Freezer
Crosley	XRE18GGA****	Top Freezer
Crosley	XRE18GGA****	Top Freezer
Crosley Professional	ZFEH2848A*	Bottom Freezer
Crosley Professional	ZRSEH268A*	Side-by-Side
DCS	RS36(X)	Bottom Freezer
DCS	RS36(X)	Bottom Freezer
DCS	RS36(X)	Bottom Freezer
DCS	RS36A80 - DCS	Bottom Freezer
Dacor	DRF36530***	Bottom Freezer
Dacor	DRF36750***	Bottom Freezer
Dacor	DRF36C500**	Bottom Freezer
Dacor	DRF36C700**	Bottom Freezer
Dacor	DRF42530***	Bottom Freezer
Dacor	DRF42750***	Bottom Freezer
Dacor	DRF485300**	Bottom Freezer
Dacor	DRF487500**	Bottom Freezer
Dacor	DRR24980***	Freezerless and Single Door
Dacor	DRR30980***	Freezerless and Single Door
Dacor	DRR36980***	Freezerless and Single Door
Dacor	DRS425300**	Side-by-Side
Dacor	DYF42BSIWS	Side-by-Side
Danby	DAR110A3*	Freezerless and Single Door
Danby	DBM187E1SSDB	Bottom Freezer
Danby	DBM187E1SSDB	Bottom Freezer
Danby	DBM187E1WDB	Bottom Freezer

Danby	DBM187E1WDB	Bottom Freezer
Danby	DBMF100B1SLDB	Bottom Freezer
Danby	DBMF100B1WDB	Bottom Freezer
Danby	DBMF100C1SLDB	Bottom Freezer
Danby	DFF101B1BSSDB	Top Freezer
Danby	DFF101B2WDB	Top Freezer
Danby	DFF116B1WDBR	Top Freezer
Danby	DFF116B2*****	Top Freezer
Danby	DFF116B2WDBL	Top Freezer
Danby	DFF116B2WDBR	Top Freezer
Danby	DFF121C2*	Top Freezer
Danby	DFF121C2WDBL	Top Freezer
Danby	DFF121C2WDBR	Top Freezer
Danby	DFF142E1SSDB	Top Freezer
Danby	DFF142E1WDB	Top Freezer
Danby	DFF143V1SSDB	Top Freezer
Danby	DFF176B1*****	Top Freezer
Danby	DFF176B1SLDB	Top Freezer
Danby	DFF176B1WDB	Top Freezer
Danby	Icemaker-Ready Product (with icemaker)	Bottom Freezer
Danby	Icemaker-Ready Product (with icemaker)	Bottom Freezer
Danby	Icemaker-Ready Product (without icemaker)	Bottom Freezer
Danby	Icemaker-Ready Product (without icemaker)	Bottom Freezer
Danby Designer	DAR110A1*	Freezerless and Single Door
Danby Designer	DAR110A1TDD	Freezerless and Single Door
Danby Designer	DAR170A3*	Freezerless and Single Door
Direct Supply	0-3F6GK	Top Freezer
ELEMENT	EHUF21*****	Freezerless and Single Door
ELEMENT	EHUF21CECS	Freezerless and Single Door
ELEMENT	EHUF21CECW	Freezerless and Single Door
ELEMENT	ENR10TFGB**	Top Freezer
ELEMENT	ENR18TFGC*	Top Freezer
ELEMENT	ERBM19***	Bottom Freezer
ELEMENT	ERBM19***	Bottom Freezer
ELEMENT	ERBM19CB*	Bottom Freezer
ELEMENT	ERFD19CGC*	Bottom Freezer
ELEMENT	ERFD19CGC*	Bottom Freezer
ELEMENT	ERT14CS**	Top Freezer
ELEMENT	ERT16CGD*	Top Freezer
ELEMENT	ERT16CGD*-CA	Top Freezer
ELEMENT	ERT18CS**	Top Freezer
ELEMENT	ERT18CSE*	Top Freezer
ELEMENT	ERT18CSEB	Top Freezer
ELEMENT	ERT18CSES	Top Freezer
ELEMENT	ERT18CSEW	Top Freezer
ELEMENT	ERT21CS**	Top Freezer
ELEMENT	EUF14CE**	Freezerless and Single Door

ELEMENT	EUF17CE**	Freezerless and Single Door
ELLIPSE	EDRT180S	Top Freezer
ELLIPSE	EDRT180W	Top Freezer
ELLIPSE	EFRBI1821-30**	Freezerless and Single Door
ELLIPSE	EFVC13S	Freezerless and Single Door
ELLIPSE	EFVC13W	Freezerless and Single Door
ELLIPSE	EFVC14W	Freezerless and Single Door
ELLIPSE	EFVC16S	Freezerless and Single Door
ELLIPSE	ERBM104S	Bottom Freezer
ELLIPSE	ERQE165S	Bottom Freezer
ELLIPSE	ERT085W	Freezerless and Single Door
ELLIPSE	ERTM180SE	Top Freezer
ELLIPSE	ERTM180WE	Top Freezer
Electrolux	EI33AR80W*	Freezerless and Single Door
Electrolux	ERFC2393A*	Bottom Freezer
Electrolux	ERFG2393A*	Bottom Freezer
Electrolux	ERMC2295A*	Bottom Freezer
Elica	EC24SRN12IPR	Freezerless and Single Door
Elica	EC24SRN12IPR-L	Freezerless and Single Door
Elica	EC30SRN16IPR	Freezerless and Single Door
Elica	EC30SRN16IPR-L	Freezerless and Single Door
Elica	ER24SRB11ISS	Bottom Freezer
Elica	ER24SRB11IVS	Bottom Freezer
Elica	ER24SRB11XSS	Bottom Freezer
Elica	ER24SRB11XVS	Bottom Freezer
Elica	ER30SRB161PR-L	Bottom Freezer
Elica	ER30SRB161PR-R	Bottom Freezer
Elica	ER36FRB191PR	Bottom Freezer
Elica	ER36FRB191PS	Bottom Freezer
Elica	ER36SRB191PR-L	Bottom Freezer
Elica	ER36SRB191PR-R	Bottom Freezer
Elisii	Brand Name: Elisii	Bottom Freezer
Elisii	Brand Name: Elisii	Bottom Freezer
Elisii	Brand Name: Elisii	Bottom Freezer
Elisii	DECVC138S2	Freezerless and Single Door
Elisii	DECVC138W2	Freezerless and Single Door
Elisii	DERTM115**1	Top Freezer
Elisii	DERTM115WW1	Top Freezer
Elisii	DERTM142*W1	Top Freezer
Elisii	DERTM180SW2	Top Freezer
Elisii	DERTM180WW2	Top Freezer
Elisii	DERTM181*W3	Top Freezer
Elisii	DERTM201BW1	Top Freezer
Elisii	DERTM201SW1	Top Freezer
Elisii	DERTM201WW1	Top Freezer
Elisii	DERTM240BW1	Top Freezer
Elisii	DERTM240SW1	Top Freezer
Elisii	DERTM240WW1	Top Freezer
Elisii	DFDBM184*W1	Bottom Freezer
Elisii	DFDBM184*W1	Bottom Freezer
Elisii	DFFFD1783-36BLK	Bottom Freezer

Elisii	DFFFD1783-36S	Bottom Freezer
Elisii	DFFFD1783-36WHT	Bottom Freezer
Elisii	DFRBI1821-30**	Freezerless and Single Door
Elisii	without ice maker	Top Freezer
Elisii	without ice maker	Top Freezer
Elisii	without ice maker	Top Freezer
Equator	RF142S	Top Freezer
Equator	RFI 1200 S	Bottom Freezer
EuroDesign	EDBM192SE	Bottom Freezer
EuroDesign	EDR085S	Freezerless and Single Door
EuroDesign	RDBM191**	Bottom Freezer
FARBERWARE	FW-FRF192	Bottom Freezer
FARBERWARE	FW-RF262-I6A	Top Freezer
FARBERWARE	FW-UFR141-I3B	Freezerless and Single Door
FARBERWARE	FW-UFR171-I3B	Freezerless and Single Door
FARBERWARE	FW-UFR211-I3B	Freezerless and Single Door
FINLUX	463 TMF1400WH	Top Freezer
FINLUX	463 TMF1412BL	Top Freezer
FINLUX	463 TMF1424SSL	Top Freezer
FINLUX	463 TMF1436RSS	Top Freezer
FORNO, Elisii	FFFFD1791-33WHT	Top Freezer
FORNO, Elisii	FFFFD1791-33BLK	Top Freezer
FORNO, Elisii	FFFFD1791-33RED	Top Freezer
FORNO, Elisii	DFFFD1791-33WHT	Top Freezer
FORNO, Elisii	DFFFD1791-33BLK	Top Freezer
FORNO, Elisii	DFFFD1791-33RED	Top Freezer
FORTE	F12BFRESIC450PR	Bottom Freezer
FORTE	F17UFESC450PR	Freezerless and Single Door
FORTE	F9BFRESIC450PR	Bottom Freezer
FORTE	F9BFRESIC450PR	Bottom Freezer
FORTE;KUCHT	F16BFRESC450PR	Bottom Freezer
FORTE;KUCHT	F16BFRESC450SS	Bottom Freezer
FORTE;KUCHT	KR300SD	Bottom Freezer
FORZA	Employ compressor VFL100CY1	Bottom Freezer
FORZA	FF36FBMS	Bottom Freezer
FULGOR MILANO	F6FBM36S2	Bottom Freezer
FULGOR MILANO	FM1BM22FBI	Bottom Freezer
FULGOR MILANO	FM4BM22IFBI	Bottom Freezer
FULGOR MILANO	FM4BM28IFBI	Bottom Freezer
FULGOR MILANO	FM4CR24FBI	Freezerless and Single Door
FULGOR MILANO	FM4CR30FBI	Freezerless and Single Door
FULGOR MILANO	FM4FBM24ISS2	Bottom Freezer
FULGOR MILANO	FM4FBM24IVS2	Bottom Freezer
FULGOR MILANO	FM4FBM24SS-BS	Top Freezer
FULGOR MILANO	FM4FBM24SS1	Bottom Freezer
FULGOR MILANO	FM4FBM24SS2	Bottom Freezer
FULGOR MILANO	FM4FBM24VS2	Bottom Freezer
FULGOR MILANO	FM4FBM28SS1	Bottom Freezer
FULGOR MILANO	FM4FBM30SS	Bottom Freezer
FULGOR MILANO	FM4FBM36SS	Bottom Freezer

FULGOR MILANO	FM6BM36IFBI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	FM4BM36BS	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	FM4BM36FBI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	FM4FBM36BS	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	FM4FBM36FBI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	REF36BMBPNB	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	REF36BMBXNB	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	REF36FDBPNB	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	REF36FDBXNB	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	VBBM2000ESE	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	VBBM2000EWE	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	VBFBM1950ESE	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA	VBFBM1950EWE	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	F20BFRESC450PR	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	FM4BM36IBS	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	FM4BM36IFBI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	HRBIFD36PR	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	KR360SD	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	REF36BMBZPNV	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	REF36BMBZXNV	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	S36BFR700IMBIP	Bottom Freezer

FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	VBBM2000ESEI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, HALLMAN, SAVALO	VBBM2000EWEI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	FFD20ESC450PR	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	FM4FBM36IBS	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	FM4FBM36IFBI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	HRBISBM36PR	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	KR365FD	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	RBIV-36	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	REF36FDBZPNV	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	REF36FDBZXNV	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	VBFBM1950ESEI	Bottom Freezer
FULGOR MILANO, BERTAZZONI, VITARA, FORTE, KUCHT, Zline, HALLMAN	VBFBM1950EWEI	Bottom Freezer
FULGOR MILANO, VITARA	FM4BM30BS	Bottom Freezer
FULGOR MILANO, VITARA	FM4BM30FBI	Bottom Freezer
FULGOR MILANO, VITARA	FM4BM30IBS	Bottom Freezer
FULGOR MILANO, VITARA	FM4BM30IFBI	Bottom Freezer
FULGOR MILANO, VITARA	VBBM1600ESE	Bottom Freezer
FULGOR MILANO, VITARA	VBBM1600EWE	Bottom Freezer
FULGOR MILANO, VITARA	VBBM1601ESE	Bottom Freezer
FULGOR MILANO, VITARA	VBBM1601EWE	Bottom Freezer
FULGOR MILANO, VITARA, FORTE	F12BFRESC450PR	Bottom Freezer
FULGOR MILANO, VITARA, FORTE	FM4BM28FBI	Bottom Freezer
FULGOR MILANO, VITARA, FORTE	VBBM1200EWE	Bottom Freezer
Fhiaba	KS300TST3IU	Bottom Freezer

Fhiaba	KS300TST6IU	Bottom Freezer
Fhiaba	KS360TST3IU	Bottom Freezer
Fhiaba	KS360TST6IU	Bottom Freezer
Fhiaba	S300TST3IU	Bottom Freezer
Fhiaba	S300TST6IU	Bottom Freezer
Fhiaba	S360TST3IU	Bottom Freezer
Fhiaba	S360TST6IU	Bottom Freezer
Fisher & Paykel	E522B****	Bottom Freezer
Fisher & Paykel	RB2470BRV1	Bottom Freezer
Fisher & Paykel	RF135B****	Bottom Freezer
Fisher & Paykel	RF135B***J**	Bottom Freezer
Fisher & Paykel	RF135B***U**	Bottom Freezer
Fisher & Paykel	RF170A****	Bottom Freezer
Fisher & Paykel	RF170A***J**	Bottom Freezer
Fisher & Paykel	RF170A***U**	Bottom Freezer
Fisher & Paykel	RF170B****	Bottom Freezer
Fisher & Paykel	RF170B***J**	Bottom Freezer
Fisher & Paykel	RF170B***U**	Bottom Freezer
Fisher & Paykel	RF170W****	Bottom Freezer
Fisher & Paykel	RF170W***J**	Bottom Freezer
Fisher & Paykel	RF170W***U**	Bottom Freezer
Fisher & Paykel	RF172****	Bottom Freezer
Fisher & Paykel	RF201A****	Bottom Freezer
Fisher & Paykel	RF201A***J**	Bottom Freezer
Fisher & Paykel	RF201A***U**	Bottom Freezer
Fisher & Paykel	RF203****	Bottom Freezer
Fisher & Paykel	RF203QDUVX1	Bottom Freezer
Fisher & Paykel	RS2474BRU1	Bottom Freezer
Fisher & Paykel	RS2474S3**#	Freezerless and Single Door
Fisher & Paykel	RS2484V*2K1	Cooler
Fisher & Paykel	RS2484W***#	Bottom Freezer
Fisher & Paykel	RS2484W*E* Ice & Water	Bottom Freezer
Fisher & Paykel	RS2484WLUK1	Bottom Freezer
Fisher & Paykel	RS2484WRU1	Bottom Freezer
Fisher & Paykel	RS2484WRUK1	Bottom Freezer
Fisher & Paykel	RS24S	Freezerless and Single Door
Fisher & Paykel	RS24SH*E*	Freezerless and Single Door
Fisher & Paykel	RS3084W***#	Bottom Freezer
Fisher & Paykel	RS3084W*E* Ice & Water	Bottom Freezer
Fisher & Paykel	RS3084WLU1	Bottom Freezer
Fisher & Paykel	RS3084WLUK1	Bottom Freezer
Fisher & Paykel	RS3084WRU1	Bottom Freezer
Fisher & Paykel	RS3084WRUK1	Bottom Freezer
Fisher & Paykel	RS30S	Freezerless and Single Door
Fisher & Paykel	RS30SH*E*	Freezerless and Single Door
Fisher & Paykel	RS32(X)	Bottom Freezer
Fisher & Paykel	RS36(X)	Bottom Freezer
Fisher & Paykel	RS3684W* Ice & Water	Bottom Freezer
Fisher & Paykel	RS36A80	Bottom Freezer
Fisher & Paykel	RS36W(X)	Bottom Freezer
Forno	ETB72U6L	Bottom Freezer

Forno	ETB72U6L	Bottom Freezer
Forno	ETB72U6L	Bottom Freezer
Forno	TB1112HY	Bottom Freezer
Forno	TB1112HY	Bottom Freezer
Forno	TB1112HY	Bottom Freezer
Forno	Brand Name: FORNO	Bottom Freezer
Forno	Brand Name: FORNO	Bottom Freezer
Forno	Brand Name: FORNO	Bottom Freezer
Forno	Compressor options: EZ65H1Y-U	Bottom Freezer
Forno	Compressor options: EZ65H1Y-U	Bottom Freezer
Forno	Compressor options: EZ65H1Y-U	Bottom Freezer
Forno	Employ compressor VFL090CY1	Bottom Freezer
Forno	Employ compressor VFL090CY1	Bottom Freezer
Forno	Employ compressor VFL110CY1	Side-by-Side
Forno	Employ compressor VFL110CY1	Side-by-Side
Forno	FFFFD1778-24LS	Bottom Freezer
Forno	FFFFD1778-24RS	Bottom Freezer
Forno	FFFFD1783-36BLK	Bottom Freezer
Forno	FFFFD1783-36S	Bottom Freezer
Forno	FFFFD1783-36WHT	Bottom Freezer
Forno	FFFFD1785-31BLK	Bottom Freezer
Forno	FFFFD1785-31S	Bottom Freezer
Forno	FFFFD1785-31WHT	Bottom Freezer
Forno	FFFFD1786-31BLK	Bottom Freezer
Forno	FFFFD1786-31S	Bottom Freezer
Forno	FFFFD1786-31WHT	Bottom Freezer
Forno	FFFFD1866-36SB	Bottom Freezer
Forno	FFFFD1974-31**	Bottom Freezer
Forno	FFFFD1974-31BLK	Bottom Freezer
Forno	FFFFD1974-31WHT	Bottom Freezer
Forno	FFRBI1805-33BLK	Side-by-Side
Forno	FFRBI1805-33SB	Side-by-Side
Forno	FFRBI1805-33WHT	Side-by-Side
Forno	FFRBI1820-36**	Bottom Freezer
Forno	FFRBI1820-36BLK	Bottom Freezer
Forno	FFRBI1820-36S	Bottom Freezer
Forno	FFRBI1820-36WHT	Bottom Freezer
Forno	FFRBI1821-30	Freezerless and Single Door
Forno	FFRBI1844-36**	Side-by-Side
Forno	FFRBI1844-36BLK	Side-by-Side
Forno	FFRBI1844-36WHT	Side-by-Side
Frestec	FR 1002 BK	Top Freezer
Frestec	FR 1002 BKB	Top Freezer
Frestec	FR 1002 SL	Top Freezer

Frestec	FR 1002 SLB	Top Freezer
Frestec	FR 1002 WH	Top Freezer
Frestec	FR 1002 WHB	Top Freezer
Frestec	FR 1202 BK	Top Freezer
Frestec	FR 1202 SL	Top Freezer
Frestec	FR 1202 WH	Top Freezer
Frestec	FR 1462 BK	Top Freezer
Frestec	FR 1462 SL	Top Freezer
Frestec	FR 1462 WH	Top Freezer
Frestec	FR 1802 BK	Top Freezer
Frestec	FR 1802 SL	Top Freezer
Frestec	FR 1802 WH	Top Freezer
Frestec	FR 2002 SL	Top Freezer
Frestec	FR 2002 WH	Top Freezer
Frigidaire	DGHX2655T*	Side-by-Side
Frigidaire	FFET1022U*	Top Freezer
Frigidaire	FFET1222U*	Top Freezer
Frigidaire	FFHB2750T*	Bottom Freezer
Frigidaire	FFHD2250T*	Bottom Freezer
Frigidaire	FFHI1832T*	Top Freezer
Frigidaire	FFHI1835V*	Top Freezer
Frigidaire	FFHI1835X*	Top Freezer
Frigidaire	FFHN2740P**A	Bottom Freezer
Frigidaire	FFHN2750T*	Bottom Freezer
Frigidaire	FFHT1425V*	Top Freezer
Frigidaire	FFHT1425V*	Top Freezer
Frigidaire	FFHT1814W*	Top Freezer
Frigidaire	FFHT1814W*	Top Freezer
Frigidaire	FFHT1814X*	Top Freezer
Frigidaire	FFHT1814X*	Top Freezer
Frigidaire	FFHT1820V*	Top Freezer
Frigidaire	FFHT1820V*	Top Freezer
Frigidaire	FFHT1822UB	Top Freezer
Frigidaire	FFHT1822UV	Top Freezer
Frigidaire	FFHT1822UW	Top Freezer
Frigidaire	FFHT1824U*	Top Freezer
Frigidaire	FFHT1835V*	Top Freezer
Frigidaire	FFHT1835V*	Top Freezer
Frigidaire	FFHT1835X*	Top Freezer
Frigidaire	FFHT1835X*	Top Freezer
Frigidaire	FFHT2022A*	Top Freezer
Frigidaire	FFHT2022A*	Top Freezer
Frigidaire	FFHT2033V*	Top Freezer
Frigidaire	FFHT2033V*	Top Freezer
Frigidaire	FFHT2045V*	Top Freezer
Frigidaire	FFHT2045V*	Top Freezer
Frigidaire	FFHT2045X*	Top Freezer
Frigidaire	FFHT2045X*	Top Freezer
Frigidaire	FFHX2325T*	Side-by-Side
Frigidaire	FG4H2272UF	Bottom Freezer
Frigidaire	FG4H2272UF1	Bottom Freezer

Frigidaire	FGHB2868T*	Bottom Freezer
Frigidaire	FGHD2368T*	Bottom Freezer
Frigidaire	FGHG2368T*	Bottom Freezer
Frigidaire	FGHN2868T*	Bottom Freezer
Frigidaire	FGHT2055V*	Top Freezer
Frigidaire	FGHT2055V*	Top Freezer
Frigidaire	FPHT2097V*	Top Freezer
Frigidaire	FPHT2097V*	Top Freezer
Frigidaire	FPRU19F8W*	Freezerless and Single Door
Frigidaire	FRAE2022A*	Freezerless and Single Door
Frigidaire	FRAE2024A*	Freezerless and Single Door
Frigidaire	FRBG1224AV	Bottom Freezer
Frigidaire	FRFC2323A*	Bottom Freezer
Frigidaire	FRFG1723A*	Bottom Freezer
Frigidaire	FRFG1813A*	Bottom Freezer
Frigidaire	FRFG2033AV	Bottom Freezer
Frigidaire	FRFG232LAF	Bottom Freezer
Frigidaire	FRFN2813A*	Bottom Freezer
Frigidaire	FRFN2823A*	Bottom Freezer
Frigidaire	FRFS2823A*	Bottom Freezer
Frigidaire	FRFS282LAF	Bottom Freezer
Frigidaire	FRMS2733A*	Bottom Freezer
Frigidaire	FRMS274TA*	Bottom Freezer
Frigidaire	FRSS2323A*	Side-by-Side
Frigidaire	FRSS2333A*	Side-by-Side
Frigidaire	FRSS2623A*	Side-by-Side
Frigidaire	FRSS2633A*	Side-by-Side
Frigidaire	FRSS26L3A*	Side-by-Side
Frigidaire	FRTE1622AB	Top Freezer
Frigidaire	FRTE1622AS	Top Freezer
Frigidaire	FRTE1622AW	Top Freezer
Frigidaire	FRTE1830AB	Top Freezer
Frigidaire	FRTE1830AV	Top Freezer
Frigidaire	FRTE1830AW	Top Freezer
Frigidaire	FRTE1835AS	Top Freezer
Frigidaire	FRTE1835AV	Top Freezer
Frigidaire	FRTI1835AB	Top Freezer
Frigidaire	FRTI1835AS	Top Freezer
Frigidaire	FRTI1835AW	Top Freezer
Frigidaire	GRBN2012A*	Bottom Freezer
Frigidaire	GRFC2353A*	Bottom Freezer
Frigidaire	GRFG2353A*	Bottom Freezer
Frigidaire	GRFN2023A*	Bottom Freezer
Frigidaire	GRFN2853A*	Bottom Freezer
Frigidaire	GRFS2853A*	Bottom Freezer
Frigidaire	GRFS287DA*	Bottom Freezer
Frigidaire	GRMC2273B*	Bottom Freezer
Frigidaire	GRMC2273C*	Bottom Freezer
Frigidaire	GRMG2272C*	Bottom Freezer
Frigidaire	GRMN2872A*	Bottom Freezer
Frigidaire	GRMS2773A*	Bottom Freezer

Frigidaire	GRQC2255B*	Bottom Freezer
Frigidaire	GRSC2352A*	Side-by-Side
Frigidaire	GRSN2620A*	Side-by-Side
Frigidaire	GRSS2352A*	Side-by-Side
Frigidaire	GRSS2652A*	Side-by-Side
Frigidaire	GRTE2055A*	Top Freezer
Frigidaire	GRTE2055A*	Top Freezer
Frigidaire	LFHB2751T*	Bottom Freezer
Frigidaire	LFHD2251T*	Bottom Freezer
Frigidaire	LFHG2251T*	Bottom Freezer
Frigidaire	LGHB2869T*	Bottom Freezer
Frigidaire	LGHK2336T*	Side-by-Side
Frigidaire	LGHX2636T*	Side-by-Side
Frigidaire	PRDA1922A*	Freezerless and Single Door
Frigidaire	PRFC2383A*	Bottom Freezer
Frigidaire	PRFG2383A*	Bottom Freezer
Frigidaire	PRFS2883A*	Bottom Freezer
Frigidaire	PRMC2285A*	Bottom Freezer
Frigidaire	PRSC2222A*	Side-by-Side
GE	GBE17HYR****	Bottom Freezer
GE	GBE21AGK****	Bottom Freezer
GE	GBE21AYR****	Bottom Freezer
GE	GBE21DGK****	Bottom Freezer
GE	GBE21DGK****	Bottom Freezer
GE	GBE21DYK****	Bottom Freezer
GE	GBE21DYK****	Bottom Freezer
GE	GDE21DGK****	Bottom Freezer
GE	GDE21DMK****	Bottom Freezer
GE	GDE21DYR****	Bottom Freezer
GE	GDE21EGK****	Bottom Freezer
GE	GDE21EMK****	Bottom Freezer
GE	GDE21EYK****	Bottom Freezer
GE	GDE25EYK****	Bottom Freezer
GE	GFE24JGK****	Bottom Freezer
GE	GFE24JMK****	Bottom Freezer
GE	GFE24JYK****	Bottom Freezer
GE	GFE26JEM****	Bottom Freezer
GE	GFE26JGM****	Bottom Freezer
GE	GFE26JMM****	Bottom Freezer
GE	GFE26JYM****	Bottom Freezer
GE	GFE28GEL****	Bottom Freezer
GE	GFE28GMK****	Bottom Freezer
GE	GFE28GYN****	Bottom Freezer
GE	GIE17GSN****	Top Freezer
GE	GIE18DTN****	Top Freezer
GE	GIE18GCN****	Top Freezer
GE	GIE18GSN****	Top Freezer
GE	GIE18GTN****	Top Freezer
GE	GIE19JSN****	Top Freezer
GE	GIE21GSH****	Top Freezer
GE	GIE21GTH****	Top Freezer

GE	GIE22JSN****	Top Freezer
GE	GIE22JTN****	Top Freezer
GE	GLE12HSP****	Bottom Freezer
GE	GLE12HSP****	Bottom Freezer
GE	GNE21DYR****	Bottom Freezer
GE	GNE21FMK****	Bottom Freezer
GE	GNE21FYK****	Bottom Freezer
GE	GNE25DYR****	Bottom Freezer
GE	GNE25JGK****	Bottom Freezer
GE	GNE25JMK****	Bottom Freezer
GE	GNE25JSK****	Bottom Freezer
GE	GNE25JYK****	Bottom Freezer
GE	GNE27JGM****	Bottom Freezer
GE	GNE27JMM****	Bottom Freezer
GE	GNE27JYM****	Bottom Freezer
GE	GNE29GMK****	Bottom Freezer
GE	GNE29GYN****	Bottom Freezer
GE	GPE12FGK****	Top Freezer
GE	GPE12FGK****	Top Freezer
GE	GPE12FSK****	Top Freezer
GE	GPE12FSK****	Top Freezer
GE	GPE17CTN****	Top Freezer
GE	GPE17CTN****	Top Freezer
GE	GSE23GGP****	Side-by-Side
GE	GSE23GYP****	Side-by-Side
GE	GSE25GGP****	Side-by-Side
GE	GSE25GYP****	Side-by-Side
GE	GTE16DTN****	Top Freezer
GE	GTE16DTN****	Top Freezer
GE	GTE16GTN****	Top Freezer
GE	GTE16GTN****	Top Freezer
GE	GTE17DTN****	Top Freezer
GE	GTE17DTN****	Top Freezer
GE	GTE17GSN****	Top Freezer
GE	GTE17GSN****	Top Freezer
GE	GTE17GTN****	Top Freezer
GE	GTE17GTN****	Top Freezer
GE	GTE18DCN****	Top Freezer
GE	GTE18DCN****	Top Freezer
GE	GTE18DTN****	Top Freezer
GE	GTE18DTN****	Top Freezer
GE	GTE18FSL****	Top Freezer
GE	GTE18FTL****	Top Freezer
GE	GTE18GMN****	Top Freezer
GE	GTE18GMN****	Top Freezer
GE	GTE18GSN****	Top Freezer
GE	GTE18GSN****	Top Freezer
GE	GTE18GTN****	Top Freezer
GE	GTE18GTN****	Top Freezer
GE	GTE18MSR****	Top Freezer
GE	GTE18MTR****	Top Freezer

GE	GTE18NSW****	Top Freezer
GE	GTE19DTN****	Top Freezer
GE	GTE19DTN****	Top Freezer
GE	GTE19JSN****	Top Freezer
GE	GTE19JSN****	Top Freezer
GE	GTE19JTN****	Top Freezer
GE	GTE19JTN****	Top Freezer
GE	GTE21GSH****	Top Freezer
GE	GTE21GSH****	Top Freezer
GE	GTE21GTH****	Top Freezer
GE	GTE21GTH****	Top Freezer
GE	GTE22JMN****	Top Freezer
GE	GTE22JMN****	Top Freezer
GE	GTE22JTN****	Top Freezer
GE	GTE22JTN****	Top Freezer
GE	GWE19JGL****	Bottom Freezer
GE	GWE19JML****	Bottom Freezer
GE	GWE19JSL****	Bottom Freezer
GE	GWE19JYL****	Bottom Freezer
GE	GWE22JYM****	Bottom Freezer
GE	GWE23GEN****	Bottom Freezer
GE	GWE23GMN****	Bottom Freezer
GE	GWE23GYN****	Bottom Freezer
GE	GYE18JEM****	Bottom Freezer
GE	GYE18JML****	Bottom Freezer
GE	GYE18JSL****	Bottom Freezer
GE	GYE18JYL****	Bottom Freezer
GE	GYE21JYM****	Bottom Freezer
GE	GYE22GEN****	Bottom Freezer
GE	GYE22GMN****	Bottom Freezer
GE	GYE22GYN****	Bottom Freezer
GE Adora	DFE24JYR****	Bottom Freezer
GE Profile	PAD28BYT****	Bottom Freezer
GE Profile	PAE28BYT****	Bottom Freezer
GE Profile	PFE24HGL****	Bottom Freezer
GE Profile	PFE24HML****	Bottom Freezer
GE Profile	PFE24HYR****	Bottom Freezer
GE Profile	PFE28KBL****	Bottom Freezer
GE Profile	PFE28KMK****	Bottom Freezer
GE Profile	PFE28KYN****	Bottom Freezer
GE Profile	PFE28PYN****	Bottom Freezer
GE Profile	PGD29BYT****	Bottom Freezer
GE Profile	PGE29BYT****	Bottom Freezer
GE Profile	PHD23BYW****	Bottom Freezer
GE Profile	PJD23BYW****	Bottom Freezer
GE Profile	PJE23BYW****	Bottom Freezer
GE Profile	PNE21NGL****	Bottom Freezer
GE Profile	PNE21NML****	Bottom Freezer
GE Profile	PNE21NYR****	Bottom Freezer
GE Profile	PNE25JGK****	Bottom Freezer
GE Profile	PNE25JMK****	Bottom Freezer

GE Profile	PNE25JSK****	Bottom Freezer
GE Profile	PNE25NGL****	Bottom Freezer
GE Profile	PNE25NML****	Bottom Freezer
GE Profile	PNE25NYR****	Bottom Freezer
GE Profile	PSE25KYH****	Side-by-Side
GE Profile	PVD28BYNB***	Bottom Freezer
GE Profile	PVD28BYNC***	Bottom Freezer
GE Profile	PVD28BYND***	Bottom Freezer
GE Profile	PVD28BYNE***	Bottom Freezer
GE Profile	PVD28BYNF***	Bottom Freezer
GE Profile	PVD28BYNG***	Bottom Freezer
GE Profile	PVD28BYNH***	Bottom Freezer
GE Profile	PWE23KEL****	Bottom Freezer
GE Profile	PWE23KMK****	Bottom Freezer
GE Profile	PWE23KYN****	Bottom Freezer
GE Profile	PXD22BYP****	Bottom Freezer
GE Profile	PYE18HML****	Bottom Freezer
GE Profile	PYE18HYR****	Bottom Freezer
GE Profile	PYE22KBL****	Bottom Freezer
GE Profile	PYE22KEL****	Bottom Freezer
GE Profile	PYE22KMK****	Bottom Freezer
GE Profile	PYE22KYN****	Bottom Freezer
GE Profile	PYE22PYN****	Bottom Freezer
GOLDEN	BCD398	Top Freezer
GOLDEN	BCD510*	Top Freezer
GOLDEN	BCD510**	Top Freezer
GOLDEN	BVIREF18SS	Top Freezer
GOLDEN	BVIREF18W	Top Freezer
GOLDEN	GRD18GH*****	Top Freezer
GOLDEN	GRD18GHB	Top Freezer
GOLDEN	GRD18GHS	Top Freezer
GOLDEN	GRD18GHW	Top Freezer
GOLDEN	GUF21GHS	Freezerless and Single Door
GRANDEUR	UFDMH224AS	Bottom Freezer
GRANDEUR	UFDMH226AS	Bottom Freezer
Gaggenau	RB280703	Bottom Freezer
Gaggenau	RB282705	Bottom Freezer
Gaggenau	RB472701	Bottom Freezer
Gaggenau	RB472704	Bottom Freezer
Gaggenau	RB472705	Bottom Freezer
Gaggenau	RB492704	Bottom Freezer
Gaggenau	RB492705	Bottom Freezer
Gaggenau	RC462701	Freezerless and Single Door
Gaggenau	RC462704	Freezerless and Single Door
Gaggenau	RC462705	Freezerless and Single Door
Gaggenau	RC472701	Freezerless and Single Door
Gaggenau	RC472704	Freezerless and Single Door
Gaggenau	RC472705	Freezerless and Single Door
Gaggenau	RC492704	Freezerless and Single Door
Gaggenau	RC492705	Freezerless and Single Door
Gaggenau	RVB477790	Bottom Freezer

Gaggenau	RVB497790	Bottom Freezer
Gaggenau	RVY497790	Bottom Freezer
Gaggenau	RY492701	Bottom Freezer
Gaggenau	RY492704	Bottom Freezer
Gaggenau	RY492705	Bottom Freezer
Galanz	BCD-510WTEI(N)-B-62H	Bottom Freezer
Galanz	BD-305WE-B-A-62H	Freezerless and Single Door
Galanz	BD-305WE-B-A1-62H	Freezerless and Single Door
Galanz	GLF11URDG16	Freezerless and Single Door
Galanz	GLF11US2A16	Freezerless and Single Door
Galanz	GLF11UWEA16	Freezerless and Single Door
Galanz	GLR10T**EF	Top Freezer
Galanz	GLR10T**EFR	Top Freezer
Galanz	GLR10TBKEFR	Top Freezer
Galanz	GLR10TRDEFR	Top Freezer
Galanz	GLR12B**E08	Bottom Freezer
Galanz	GLR12B**R16	Bottom Freezer
Galanz	GLR12T**EFR	Top Freezer
Galanz	GLR12TBKEFR	Top Freezer
Galanz	GLR12TBKF	Top Freezer
Galanz	GLR12TRDEFR	Top Freezer
Galanz	GLR12TS5F	Top Freezer
Galanz	GLR12TWEF	Top Freezer
Galanz	GLR16F**E16	Bottom Freezer
Galanz	GLR18F**S16	Bottom Freezer
Galanz	GLR18TM**EM03	Bottom Freezer
Gladiator	GARF30FDGB**	Freezerless and Single Door
Gorenje	HZF3267SCD	Bottom Freezer
Gorenje	HZF3267SED	Bottom Freezer
Gorenje	HZF3567SED	Bottom Freezer
Gorenje	VCS5297TPGVCS5297TPG	Cooler
Gorenje	WCN311942G	Cooler
Gorenje	WCN311942GW	Cooler
HALLMAN	HBBIBMWDIML36SS	Bottom Freezer
HALLMAN	HBFSBMID24SS	Bottom Freezer
HALLMAN	HBFSBMID24VS	Bottom Freezer
HALLMAN	HBFSBMIDIM24SS	Bottom Freezer
HALLMAN	HBFSBMIDIM24VS	Bottom Freezer
HALLMAN	HCLFSBMID24SS	Bottom Freezer
HALLMAN	HCLFSBMID24VS	Bottom Freezer
HALLMAN	HCLFSBMIDIM24SS	Bottom Freezer
HALLMAN	HCLFSBMIDIM24VS	Bottom Freezer
HALLMAN	HRBIAR24PR	Freezerless and Single Door
HALLMAN	HRBIAR30PR	Freezerless and Single Door
HESTAN	KRFR36PRI	Bottom Freezer
HOUSE KOBO	HD-663FWEN	Top Freezer
HOUSE KOBO	UR-BCD398WE-SQ-**	Top Freezer
HOUSE KOBO	UR-BCD572WX-SQ-WZ	Top Freezer
HOUSE KOBO	UR-BCD636WE-ST-WZ	Bottom Freezer
HOUSE KOBO	WZTMF18***	Top Freezer
HOUSE KOBO	WZTMF18***	Top Freezer

Haier	HRB15N3B**	Bottom Freezer
Haier	HRQ16N3B**	Bottom Freezer
Haier	QHE16HYP****	Bottom Freezer
Haier	QHE16HYP****	Bottom Freezer
Haier	QNE27JYM****	Bottom Freezer
Hamilton Beach	BC-396	Freezerless and Single Door
Hamilton Beach	Employ compressor VFL090CY1	Bottom Freezer
Hamilton Beach	Employ compressor VTB1113Y	Bottom Freezer
Hamilton Beach	HBF1558/HZ8551	Side-by-Side
Hamilton Beach	HBF1662	Bottom Freezer
Hamilton Beach	HBF1663-SSBLACK	Bottom Freezer
Hamilton Beach	HBF1770	Bottom Freezer
Hamilton Beach	HBF1770/HZ0771	Bottom Freezer
Hamilton Beach	HBF1772	Bottom Freezer
Hamilton Beach	HBF1800	Bottom Freezer
Hamilton Beach	HBF2064/HZ4602	Side-by-Side
Hamilton Beach	HBF2065-SSBLACK	Side-by-Side
Hamilton Beach	HBF2067	Bottom Freezer
Hamilton Beach	HBF2067/HZ7602	Bottom Freezer
Hamilton Beach	HBFRF1495-B-3BCOM	Freezerless and Single Door
Hamilton Beach	HZ4051	Bottom Freezer
Hamilton Beach	HZ49411494-B	Freezerless and Single Door
Hisense	TB1112HY	Bottom Freezer
Hisense	VTH1113YG)	Bottom Freezer
Hisense	means different control panel.	Bottom Freezer
Hisense	2 compressor options:EZ65H1Y-U	Bottom Freezer
Hisense	BCD-300WY2NA1/HC1(E)	Bottom Freezer
Hisense	BCD-320WP4NA1/HC1(H)	Top Freezer
Hisense	BCD-418WP4NA1/HC1(H)	Top Freezer
Hisense	BCD-422WY2NA1/HC1(H)	Bottom Freezer
Hisense	BCD-422WY2NF1/HC1(H)	Bottom Freezer
Hisense	BCD-450WYE/HC1(H)CKD	Bottom Freezer
Hisense	BCD-450WYZ/HC1(H)	Bottom Freezer
Hisense	BCD-468WY/HC	Bottom Freezer
Hisense	BCD-740WP/HC	Bottom Freezer
Hisense	BCD-740WPZR/HC	Bottom Freezer
Hisense	Brand : Hisense (Compressor options: VFL110CY1	Bottom Freezer
Hisense	Compressor VFL110CY1	Bottom Freezer
Hisense	Compressor VFL110CY1	Bottom Freezer
Hisense	Compressor VFL110CY1	Bottom Freezer
Hisense	Compressor VTH1113Y A	Bottom Freezer
Hisense	Compressor VTH1113Y A	Bottom Freezer

Hisense	FV10C7HSE	Freezerless and Single Door
Hisense	HRB148N6A*E	Bottom Freezer
Hisense	HRB171N6A*E	Bottom Freezer
Hisense	HRB171N6A*EH	Bottom Freezer
Hisense	HRB171N6B*E	Bottom Freezer
Hisense	HRB221N6ABE	Bottom Freezer
Hisense	HRB221N6ASE	Bottom Freezer
Hisense	HRB221N6AWE	Bottom Freezer
Hisense	HRB221N6B*E	Bottom Freezer
Hisense	HRF209N6C**	Bottom Freezer
Hisense	HRF209N6C*E	Bottom Freezer
Hisense	HRF210N6C*E	Bottom Freezer
Hisense	HRF220N6B*E	Bottom Freezer
Hisense	HRF220N6B*EW	Bottom Freezer
Hisense	HRF230P5BSE	Bottom Freezer
Hisense	HRF254N6D*E	Bottom Freezer
Hisense	HRF254N6T*E	Bottom Freezer
Hisense	HRF266N6C*E1	Bottom Freezer
Hisense	HRM198N6P*E	Bottom Freezer
Hisense	HRM260N6T*E	Bottom Freezer
Hisense	HRQ215N6BVE	Bottom Freezer
Hisense	HRT120P3AVE	Top Freezer
Hisense	HRT180N6A*	Top Freezer
Hisense	HRT180N6A*E	Top Freezer
Hisense	RB11N6C*E	Bottom Freezer
Hisense	RB12A2C*E	Bottom Freezer
Hisense	RB15A2C*E	Bottom Freezer
Hisense	RB15N6A*E	Bottom Freezer
Hisense	RB17A2C*E	Bottom Freezer
Hisense	RB17N6C*E	Bottom Freezer
Hisense	RB17N6D*E	Bottom Freezer
Hisense	RB17N6F*E	Bottom Freezer
Hisense	RB18A2CSE	Bottom Freezer
Hisense	RB22A2F*E	Bottom Freezer
Hisense	RF200D4C*E	Bottom Freezer
Hisense	RF208N6**E	Bottom Freezer
Hisense	RF210N6A*E	Bottom Freezer
Hisense	RF210N6W*E	Bottom Freezer
Hisense	RF21A3F*E	Bottom Freezer
Hisense	RF21B3F*E	Bottom Freezer
Hisense	RF225A3CSE	Bottom Freezer
Hisense	RF225C3C*EI	Bottom Freezer
Hisense	RF225C3CSEI	Bottom Freezer
Hisense	RF22B3F*E	Bottom Freezer
Hisense	RF22B3FSEI	Bottom Freezer
Hisense	RF254N6C*E	Bottom Freezer
Hisense	RF266C3F*E	Bottom Freezer
Hisense	RF26N6A*E	Bottom Freezer
Hisense	RF27A3F*E	Bottom Freezer
Hisense	RQ17A4CSD	Bottom Freezer
Hisense	RT12A2CSE	Top Freezer

Hisense	RT15A2CCE	Top Freezer
Hisense	RT15A2CSE	Top Freezer
Hisense	RT15A2CWE	Top Freezer
Hotpoint	HCM22QW*WW	Freezerless and Single Door
Hotpoint	HPE16BTN****	Top Freezer
Hotpoint	HPE16BTN****	Top Freezer
ILVE	RT9020BFBM	Bottom Freezer
Ikea	20462151*	Bottom Freezer
Ikea	20522287	Bottom Freezer
Ikea	40522286	Bottom Freezer
Ikea	BERGSNAS 60607883	Bottom Freezer
Ikea	FÄRSKHET	Bottom Freezer
Ikea	IRS335SDH*0*	Side-by-Side
Ikea	IRT134FD*0*	Top Freezer
Ikea	IRT134FD*0*	Top Freezer
Ikea	IRT138FD*0*	Top Freezer
Ikea	IX3HHGXSS*	Bottom Freezer
Ikea	IX3HHGXSS*	Bottom Freezer
Ikea	IX7DDEXDS*	Bottom Freezer
Ikea	IX7DDEXGZ*	Bottom Freezer
Ikea	K00462152*	Top Freezer
Ikea	K00462152*	Top Freezer
Ikea	K80462148*	Top Freezer
Ikea	K80462148*	Top Freezer
Ikea	LAGAN N 30587626	Top Freezer
Ikea	OLOFSFORS 10587608	Top Freezer
Ikea	OVERSKADLIG	Bottom Freezer
Ikea	VÄLGRUNDAD	Bottom Freezer
Insignia	NS-RBM10SS2	Bottom Freezer
Insignia	NS-RBM10WH2	Bottom Freezer
Insignia	NS-RBM11SS2	Bottom Freezer
Insignia	NS-RBM11SS2-C	Bottom Freezer
Insignia	NS-RBM11WH2	Bottom Freezer
Insignia	NS-RBM11WH2-C	Bottom Freezer
Insignia	NS-RBM18***	Bottom Freezer
Insignia	NS-RBM18SS0	Bottom Freezer
Insignia	NS-RBM18SS0-C	Bottom Freezer
Insignia	NS-RBM18WH0-C	Bottom Freezer
Insignia	NS-RTM10BK2	Top Freezer
Insignia	NS-RTM10SS2	Top Freezer
Insignia	NS-RTM10SS2-C	Top Freezer
Insignia	NS-RTM10WH2	Top Freezer
Insignia	NS-RTM10WH2-C	Top Freezer
Insignia	NS-RTM12SS7	Top Freezer
Insignia	NS-RTM12SS7	Top Freezer
Insignia	NS-RTM12SS7-C	Top Freezer
Insignia	NS-RTM14***	Top Freezer
Insignia	NS-RTM14SS5-C	Top Freezer
Insignia	NS-RTM14WH5-C	Top Freezer
Insignia	NS-RTM18****	Top Freezer
Insignia	NS-RTM18BK2	Top Freezer

Insignia	NS-RTM18BK2L	Top Freezer
Insignia	NS-RTM18SS2	Top Freezer
Insignia	NS-RTM18SS2L	Top Freezer
Insignia	NS-RTM18SS7*	Top Freezer
Insignia	NS-RTM18SS7-C	Top Freezer
Insignia	NS-RTM18WH2	Top Freezer
Insignia	NS-RTM18WH7*	Top Freezer
Insignia	NS-RTM18WH7-C	Top Freezer
Insignia	NS-RTM20**#***	Top Freezer
Insignia	NS-RTM20SS3	Top Freezer
Jenn Air	JBBF*30NMX	Bottom Freezer
Jenn Air	JBSS42E22***	Side-by-Side
Jenn Air	JBSS48E22***	Side-by-Side
Jenn Air	JBTF*30NMX **	Bottom Freezer
Jenn-Air	ALOVE24RRC0*	Freezerless and Single Door
Jenn-Air	ALOVE30RRC0*	Freezerless and Single Door
Jenn-Air	JB36NXFXLE**	Bottom Freezer
Jenn-Air	JB36NXFXRE**	Bottom Freezer
Jenn-Air	JBBFX24NHX	Bottom Freezer
Jenn-Air	JBRF*24IGX**	Freezerless and Single Door
Jenn-Air	JBRF*30IGX**	Freezerless and Single Door
Jenn-Air	JBRF*36IGX**	Freezerless and Single Door
Jenn-Air	JFC2089BE*	Bottom Freezer
Jenn-Air	JS42PPDUDE**	Side-by-Side
Jenn-Air	JS42SSDUDE**	Side-by-Side
Jenn-Air	JS48PPDUDE**	Side-by-Side
Jenn-Air	JS48SSDUDE**	Side-by-Side
JennAir	JBBFX22NMX	Bottom Freezer
JennAir	JBRFS*30RX**	Freezerless and Single Door
JennAir	JBWFNL18RX	Cooler
JennAir	JBWFNL24RX	Cooler
JennAir	JBWFNR18RX	Cooler
JennAir	JBWFNR24RX	Cooler
KOOLATRON	KTUF600-W-E	Freezerless and Single Door
KOOLMORE	KM-PRC-R24	Freezerless and Single Door
KOOLMORE	KM-PRC-R30	Freezerless and Single Door
KOOLMORE	KM-RER36-FDPR	Bottom Freezer
KOOLMORE	KM-RER36-SWPR	Bottom Freezer
KOOLMORE	KM-RERFD**-18C	Bottom Freezer
KOOLMORE	KM-RERFDSS-18C	Bottom Freezer
KOOLMORE	KM-RERFDSS-18C	Bottom Freezer
KOOLMORE	RERFDSS-22C	Bottom Freezer
KOSTCH	KOS-36RF*##* -**	Bottom Freezer
KUCHT	KR240TR	Freezerless and Single Door
KUCHT	KR300TR	Freezerless and Single Door
KUCHT	KR375FD	Bottom Freezer
KUCHT	KR700I	Bottom Freezer
KUCHT	KR900X	Bottom Freezer
Kenmore	1	Bottom Freezer
Kenmore	2 to 9	Bottom Freezer
Kenmore	2nd # is a revision number	Top Freezer

Kenmore	2nd # is a revision number	Top Freezer
Kenmore	2nd # is a revision number	Top Freezer
Kenmore	2nd # is a revision number	Top Freezer
Kenmore	2nd # represents a control number of the product	Bottom Freezer
Kenmore	2nd # represents a control number of the product	Side-by-Side
Kenmore	2nd # represents a control number of the product	Bottom Freezer
Kenmore	# refer to color	Top Freezer
Kenmore	# refer to color	Top Freezer
Kenmore	# refer to color	Top Freezer
Kenmore	# refer to color	Top Freezer
Kenmore	111.60#1####	Top Freezer
Kenmore	111.6071####	Top Freezer
Kenmore	111.6076####	Top Freezer
Kenmore	111.612#####	Top Freezer
Kenmore	111.6121####	Top Freezer
Kenmore	111.6121*61*	Top Freezer
Kenmore	111.70#1####	Top Freezer
Kenmore	111.7071####	Top Freezer
Kenmore	111.7076####	Top Freezer
Kenmore	111.712#####	Top Freezer
Kenmore	111.7121####	Top Freezer
Kenmore	111.7121*61*	Top Freezer
Kenmore	111.7269####	Bottom Freezer
Kenmore	111.7279####	Bottom Freezer
Kenmore	111.7303****	Bottom Freezer
Kenmore	111.7304*61*	Bottom Freezer
Kenmore	111.7324****	Bottom Freezer
Kenmore	111.7330****	Bottom Freezer
Kenmore	111.7331####	Bottom Freezer
Kenmore	111.7332****	Bottom Freezer
Kenmore	111.7333####	Bottom Freezer
Kenmore	111.7503####	Bottom Freezer
Kenmore	111.7550####	Bottom Freezer
Kenmore	1st # refer to color	Top Freezer
Kenmore	1st # refer to color	Top Freezer
Kenmore	1st # refer to color	Top Freezer
Kenmore	1st # refer to color	Top Freezer
Kenmore	1st # represents color of the product. 2nd # represents a control number of the product	Bottom Freezer
Kenmore	1st # represents the color of the product	Bottom Freezer
Kenmore	1st # represents the color of the product	Bottom Freezer
Kenmore	1st # represents the color of the product	Side-by-Side
Kenmore	405.7562#42#	Bottom Freezer
Kenmore	46-75625	Bottom Freezer

Kenmore	60#1#	Top Freezer
Kenmore	6071#	Top Freezer
Kenmore	6076#	Top Freezer
Kenmore	612##	Top Freezer
Kenmore	6121#	Top Freezer
Kenmore	6133#	Top Freezer
Kenmore	6231#	Top Freezer
Kenmore	6935*	Bottom Freezer
Kenmore	6935*	Bottom Freezer
Kenmore	6936*	Bottom Freezer
Kenmore	6936*	Bottom Freezer
Kenmore	6938*	Bottom Freezer
Kenmore	6938*	Bottom Freezer
Kenmore	70#1#	Top Freezer
Kenmore	7071#	Top Freezer
Kenmore	7076#	Top Freezer
Kenmore	712##	Top Freezer
Kenmore	7121#	Top Freezer
Kenmore	7133#	Top Freezer
Kenmore	7231#	Top Freezer
Kenmore	7269#	Bottom Freezer
Kenmore	7279#	Bottom Freezer
Kenmore	7331#	Bottom Freezer
Kenmore	7333#	Bottom Freezer
Kenmore	7333#	Bottom Freezer
Kenmore	7503#	Bottom Freezer
Kenmore	7550#	Bottom Freezer
Kenmore	7931***	Bottom Freezer
Kenmore	7934***	Bottom Freezer
Kenmore	7941*	Bottom Freezer
Kenmore	896.6134242	Top Freezer
Kenmore	896.6134542	Top Freezer
Kenmore	896.6134942	Top Freezer
Kenmore	896.6135242	Top Freezer
Kenmore	896.6135542	Top Freezer
Kenmore	896.6135942	Top Freezer
Kenmore	896.6136242	Top Freezer
Kenmore	896.6136542	Top Freezer
Kenmore	896.6136942	Top Freezer
Kenmore	897.5180#32#	Side-by-Side
Kenmore	897.5180532	Side-by-Side
Kenmore	897.7551#32#	Bottom Freezer
Kenmore	897.7551532	Bottom Freezer
Kenmore	897.7552#32#	Bottom Freezer
Kenmore	897.7552532	Bottom Freezer
Kenmore	897.7561#52#	Bottom Freezer
Kenmore	899.6133#32#	Top Freezer
Kenmore	899.6231#32#	Top Freezer
Kenmore	899.7133#32#	Top Freezer
Kenmore	899.7231#32#	Top Freezer
Kenmore	K*BH031A*E#	Bottom Freezer

KitchenAid	KRFC604F****	Bottom Freezer
KitchenAid	KRFF302E****	Bottom Freezer
KitchenAid	KRFF305E****	Bottom Freezer
KitchenAid	KRFF336SPS	Bottom Freezer
KitchenAid	KRFF436SBE	Bottom Freezer
KitchenAid	KRFF436SJP	Bottom Freezer
KitchenAid	KRFF436SPS	Bottom Freezer
KitchenAid	KRFF507H**0*	Bottom Freezer
KitchenAid	KRMF336SPS	Bottom Freezer
KitchenAid	KRMF436SBE	Bottom Freezer
KitchenAid	KRMF436SJP	Bottom Freezer
KitchenAid	KRMF436SPS	Bottom Freezer
KitchenAid	KRQC506M****	Bottom Freezer
KitchenAid	KRQC736R*	Bottom Freezer
KitchenAid	KRSC336R****	Side-by-Side
KitchenAid	KRSC536R****	Side-by-Side
KitchenAid	KRSF336R****	Side-by-Side
KitchenAid	KRSF505*****	Side-by-Side
KitchenAid	KRSF536R****	Side-by-Side
KitchenAid	KRSF705*****	Side-by-Side
KitchenAid	KSSC42QVS**	Side-by-Side
KitchenAid	KSSC48QVS**	Side-by-Side
Konfort	561-11579	Top Freezer
Konfort	561-11580	Top Freezer
Konfort	561-11581	Top Freezer
Konfort	561-11582	Top Freezer
L2	LRB19B5A***	Bottom Freezer
L2	LRB19B5A***	Bottom Freezer
L2	LRF18B5***	Bottom Freezer
L2	LRF18B5***	Bottom Freezer
L2	LRF29D3***	Bottom Freezer
L2	LRQ22D6***	Bottom Freezer
L2	LRQ23B4A**	Bottom Freezer
L2	LRT12B2AWW	Top Freezer
L2	LRT18S4ASTC	Top Freezer
L2	LRT18S4AWWC	Top Freezer
L2	LRU14F3ASTC	Freezerless and Single Door
L2	LRU14F3AWWC	Freezerless and Single Door
L2	LRU17B6***	Freezerless and Single Door
L2	LRU17B6A**	Freezerless and Single Door
L2	LRU21B6A**	Freezerless and Single Door
LG	LB12C2000*	Bottom Freezer
LG	LB22T2100*	Bottom Freezer
LG	LBNC12231*	Bottom Freezer
LG	LBNC12251*	Bottom Freezer
LG	LBNC15231*	Bottom Freezer
LG	LBNC15241*	Bottom Freezer
LG	LBNC15251*	Bottom Freezer
LG	LBNC15251U	Bottom Freezer
LG	LCFC26XS*	Bottom Freezer
LG	LCFS22EX*	Bottom Freezer

LG	LDCS24223*	Bottom Freezer
LG	LDNS22220*	Bottom Freezer
LG	LF19C8200*	Bottom Freezer
LG	LF20C6330*	Bottom Freezer
LG	LF20G6330*	Bottom Freezer
LG	LF20G6331*	Bottom Freezer
LG	LF21C6000*	Bottom Freezer
LG	LF21C6200*	Bottom Freezer
LG	LF21G6200*	Bottom Freezer
LG	LF21G6201*	Bottom Freezer
LG	LF22T6200*	Bottom Freezer
LG	LF22T6220*	Bottom Freezer
LG	LF24C8200*	Bottom Freezer
LG	LF24Z6530*	Bottom Freezer
LG	LF25C8330*	Bottom Freezer
LG	LF25G8330*	Bottom Freezer
LG	LF25H6000*	Bottom Freezer
LG	LF25H6200*	Bottom Freezer
LG	LF25H6330*	Bottom Freezer
LG	LF25S6000*	Bottom Freezer
LG	LF25S6200*	Bottom Freezer
LG	LF25S6330*	Bottom Freezer
LG	LF25S6560*	Bottom Freezer
LG	LF25Z6211*	Bottom Freezer
LG	LF26C6360*	Bottom Freezer
LG	LF26C8210*	Bottom Freezer
LG	LF26G8210*	Bottom Freezer
LG	LF27D6200*	Bottom Freezer
LG	LF29H8330*	Bottom Freezer
LG	LF29S8230*	Bottom Freezer
LG	LF29S8250*	Bottom Freezer
LG	LF29S8330*	Bottom Freezer
LG	LF29S8365*	Bottom Freezer
LG	LF30H8210*	Bottom Freezer
LG	LF30S8210*	Bottom Freezer
LG	LF31S6360*	Bottom Freezer
LG	LF31T6230*	Bottom Freezer
LG	LF32S6000*	Bottom Freezer
LG	LFC22770**	Bottom Freezer
LG	LFCC22426*	Bottom Freezer
LG	LFCC23596*	Bottom Freezer
LG	LFCS22520*	Bottom Freezer
LG	LFCS27596*	Bottom Freezer
LG	LFCS28768*	Bottom Freezer
LG	LFD22716**	Bottom Freezer
LG	LFD22786**	Bottom Freezer
LG	LFDS22520*	Bottom Freezer
LG	LFNS22520*	Bottom Freezer
LG	LFNS22530*	Bottom Freezer
LG	LFXC22525*	Bottom Freezer
LG	LFXC22526*	Bottom Freezer

LG	LFXC22596*	Bottom Freezer
LG	LFXS26566*	Bottom Freezer
LG	LFXS26596*	Bottom Freezer
LG	LFXS26973*	Bottom Freezer
LG	LFXS28566*	Bottom Freezer
LG	LFXS28596*	Bottom Freezer
LG	LFXS28968*	Bottom Freezer
LG	LH29S8565*	Bottom Freezer
LG	LHFS28XB*	Bottom Freezer
LG	LHSXS2706*	Side-by-Side
LG	LHTNS2403*	Top Freezer
LG	LK12S6000*	Top Freezer
LG	LK14S8000*	Freezerless and Single Door
LG	LL27T3530*	Side-by-Side
LG	LL31H6530*	Bottom Freezer
LG	LLFGC2706*	Bottom Freezer
LG	LLFOC2606*	Bottom Freezer
LG	LLMXS3006*	Bottom Freezer
LG	LMNS14420*	Freezerless and Single Door
LG	LMWC23626*	Bottom Freezer
LG	LMWS27626*	Bottom Freezer
LG	LMWS29626*	Bottom Freezer
LG	LMXC22626*	Bottom Freezer
LG	LMXS28596*	Bottom Freezer
LG	LMXS28626*	Bottom Freezer
LG	LRBCC1204*	Bottom Freezer
LG	LRBNC1104*	Bottom Freezer
LG	LRDCS2603*	Bottom Freezer
LG	LRDNC1004*	Bottom Freezer
LG	LRDNS2200*	Bottom Freezer
LG	LRFCC23D6*	Bottom Freezer
LG	LRFCS2503*	Bottom Freezer
LG	LRFCS2523*	Bottom Freezer
LG	LRFCS25D3*	Bottom Freezer
LG	LRFCS29D6*	Bottom Freezer
LG	LRFDC2406*	Bottom Freezer
LG	LRFDS3016*	Bottom Freezer
LG	RFES2503*	Bottom Freezer
LG	RFGC2706*	Bottom Freezer
LG	RFSLC2706*	Bottom Freezer
LG	RFSLC2716*	Bottom Freezer
LG	RFSL3206*	Bottom Freezer
LG	RFSL3216*	Bottom Freezer
LG	RFNS2200*	Bottom Freezer
LG	RFNS2503*	Bottom Freezer
LG	RFOC2606*	Bottom Freezer
LG	RFSS28XB*	Bottom Freezer
LG	RFVC2406*	Bottom Freezer
LG	RFVS2503*	Bottom Freezer
LG	RFWS2200*	Bottom Freezer
LG	RFWS2906*	Bottom Freezer

LG	LRFXC2416*	Bottom Freezer
LG	LRFXC2606*	Bottom Freezer
LG	LRFXS2503*	Bottom Freezer
LG	LRFXS2513*	Bottom Freezer
LG	LRFXS3106*	Bottom Freezer
LG	LRKNS1400*	Freezerless and Single Door
LG	LRMDC2306*	Bottom Freezer
LG	LRMDS3006*	Bottom Freezer
LG	LRMNC1803*	Bottom Freezer
LG	LRMNC1813*	Bottom Freezer
LG	LRMVC1803*	Bottom Freezer
LG	LRMVC2306*	Bottom Freezer
LG	LRMVS2806*	Bottom Freezer
LG	LRMVS3006*	Bottom Freezer
LG	LRMWS2906*	Bottom Freezer
LG	LRMXC1803*	Bottom Freezer
LG	LRMXC1813*	Bottom Freezer
LG	LRMXC2206*	Bottom Freezer
LG	LRMXS2806*	Bottom Freezer
LG	LRMXS3006*	Bottom Freezer
LG	LRONC1404*	Freezerless and Single Door
LG	LRONC1414*	Freezerless and Single Door
LG	LRRXC2606*	Bottom Freezer
LG	LRSDS2706*	Side-by-Side
LG	LRSOC2306*	Side-by-Side
LG	LRSOS2706*	Side-by-Side
LG	LRSVS2706*	Side-by-Side
LG	LRTLS2403*	Top Freezer
LG	LRTNC0915*	Top Freezer
LG	LRKNC2606*	Bottom Freezer
LG	LRKNS3106*	Bottom Freezer
LG	LRKXC2606*	Bottom Freezer
LG	LRKXS3106*	Bottom Freezer
LG	LS23C4000*	Side-by-Side
LG	LS27H3230*	Side-by-Side
LG	LS27T3230*	Side-by-Side
LG	LSBNC1021*	Bottom Freezer
LG	LSSB2692**	Side-by-Side
LG	LT11C2000*	Top Freezer
LG	LT13C2000*	Top Freezer
LG	LT18S1100*	Top Freezer
LG	LT18S1100*	Top Freezer
LG	LT18S1200*	Top Freezer
LG	LT18S2100*	Top Freezer
LG	LT18S2100*	Top Freezer
LG	LTCS20020*	Top Freezer
LG	LTCS20030*	Top Freezer
LG	LTNS20220*	Top Freezer
LG	SRFB27*#	Bottom Freezer
LG	SRFVC2406*	Bottom Freezer
LG	SRFVC2416*	Bottom Freezer

LG	SRSXB2622*	Side-by-Side
LG SIGNATURE	LUPXS3186*	Bottom Freezer
LG SIGNATURE	URNTC2306*	Bottom Freezer
Liebherr	C5250	Bottom Freezer
Liebherr	C5740IM	Bottom Freezer
Liebherr	C7540IM	Bottom Freezer
Liebherr	C7620	Bottom Freezer
Liebherr	CB7790IM	Bottom Freezer
Liebherr	CBS 2092	Bottom Freezer
Liebherr	CBS 2092G	Bottom Freezer
Liebherr	CS 2090	Bottom Freezer
Liebherr	CS 2090G	Bottom Freezer
Liebherr	CS 2091	Bottom Freezer
Liebherr	CS 2091G	Bottom Freezer
Liebherr	CS 2092	Bottom Freezer
Liebherr	CS 2092G	Bottom Freezer
Liebherr	CS1401R-IM	Bottom Freezer
Liebherr	CS1410	Bottom Freezer
Liebherr	CS1640B	Bottom Freezer
Liebherr	HC 1570	Bottom Freezer
Liebherr	HC 1570G	Bottom Freezer
Liebherr	HC 1571	Bottom Freezer
Liebherr	HC 1571G	Bottom Freezer
Liebherr	HC 1580	Bottom Freezer
Liebherr	HC 1580G	Bottom Freezer
Liebherr	HC 1581	Bottom Freezer
Liebherr	HC 1581G	Bottom Freezer
Liebherr	HC 2090	Bottom Freezer
Liebherr	HC 2090G	Bottom Freezer
Liebherr	HC 2091	Bottom Freezer
Liebherr	HC 2091G	Bottom Freezer
Liebherr	HC 2092	Bottom Freezer
Liebherr	HC 2092G	Bottom Freezer
Liebherr	HCB 1590	Bottom Freezer
Liebherr	HCB 1590G	Bottom Freezer
Liebherr	HCB 1591	Bottom Freezer
Liebherr	HCB 1591G	Bottom Freezer
Liebherr	HCB 2090	Bottom Freezer
Liebherr	HCB 2090G	Bottom Freezer
Liebherr	HCB 2091	Bottom Freezer
Liebherr	HCB 2091G	Bottom Freezer
Liebherr	HCB 2092	Bottom Freezer
Liebherr	HCB 2092G	Bottom Freezer
Liebherr	HW 8000	Cooler
Liebherr	IC5100PC	Bottom Freezer
Liebherr	IC5110IM	Bottom Freezer
Liebherr	IC5110IMPC	Bottom Freezer
Liebherr	ICB5160IM	Bottom Freezer
Liebherr	ICS5100	Bottom Freezer
Liebherr	ICS5101	Bottom Freezer
Liebherr	IRB5160	Freezerless and Single Door

Liebherr	IRBP5170	Freezerless and Single Door
Liebherr	MCB 3050	Bottom Freezer
Liebherr	MCB 3051	Bottom Freezer
Liebherr	MCB 3061	Bottom Freezer
Liebherr	MCB 3650	Bottom Freezer
Liebherr	MCB 3651	Bottom Freezer
Liebherr	MCB 3652	Bottom Freezer
Liebherr	MCB 3660	Bottom Freezer
Liebherr	MCB 3661	Bottom Freezer
Liebherr	MCB 3662	Bottom Freezer
Liebherr	MF 1861	Upright Freezer
Liebherr	MF 2461	Upright Freezer
Liebherr	MF 3061	Upright Freezer
Liebherr	MF 3661	Upright Freezer
Liebherr	MRB 2410	Freezerless and Single Door
Liebherr	MRB 3010	Freezerless and Single Door
Liebherr	MRB 3610	Freezerless and Single Door
Liebherr	MRB2400	Freezerless and Single Door
Liebherr	MRB3000	Freezerless and Single Door
Liebherr	MRB3600	Freezerless and Single Door
Liebherr	MW 1800	Cooler
Liebherr	MW 1801	Cooler
Liebherr	MW 2400	Cooler
Liebherr	MW 2401	Cooler
Liebherr	SC5781	Bottom Freezer
Liebherr	SC7520	Bottom Freezer
Liebherr	SC7541IM	Bottom Freezer
Liebherr	SC7751	Bottom Freezer
Liebherr	SCB5790IM	Bottom Freezer
Liebherr	SCB7760IM	Bottom Freezer
Liebherr	SRB5280	Freezerless and Single Door
Liebherr	SRB5290	Freezerless and Single Door
Liebherr	W5250	Cooler
Liebherr	W5270	Cooler
Liebherr	Wgb7470	Cooler
MARTEL	F18HF01SS	Bottom Freezer
MARTEL	F18RF01SS	Bottom Freezer
MARTEL	F18RF01SS	Bottom Freezer
Mabe	MDF25EYR****	Bottom Freezer
Mabe	MDU25ESK****	Bottom Freezer
Magic Chef	HMDR1000BE	Top Freezer
Magic Chef	HMDR1000BE	Top Freezer
Magic Chef	HMDR1000SE	Top Freezer
Magic Chef	HMDR1000ST	Top Freezer
Magic Chef	HMDR1000ST	Top Freezer
Magic Chef	HMDR1000WE	Top Freezer
Magic Chef	HMDR1000WE	Top Freezer
Magic Chef	HMDR1000WF	Top Freezer
Magic Chef	MCAR1000BE	Top Freezer
Magic Chef	MCAR1000ST	Top Freezer
Magic Chef	MCAR1000WE	Top Freezer

Magic Chef	MCBM920S1	Bottom Freezer
Magic Chef	MCBM920W1	Bottom Freezer
Magic Chef	MCDR1000BE	Top Freezer
Magic Chef	MCDR1000BF	Top Freezer
Magic Chef	MCDR1000ST	Top Freezer
Magic Chef	MCDR1000STF	Top Freezer
Magic Chef	MCDR1000WE	Top Freezer
Magic Chef	MCDR1000WF	Top Freezer
Magic Chef	MCTM18B	Top Freezer
Magic Chef	MCTM18PS	Top Freezer
Magic Chef	MCTM18W	Top Freezer
Magic Cool	MCR10***	Top Freezer
Marathon	MAR110BLS	Freezerless and Single Door
Marathon	MAR110W	Freezerless and Single Door
Marathon	MAR86BLS	Freezerless and Single Door
Marathon	MAR86W	Freezerless and Single Door
Marathon	MFF101*	Top Freezer
Marathon	MFF101W	Top Freezer
Marathon	MFF115*****	Bottom Freezer
Marathon	MFF115SSBM	Bottom Freezer
Marathon	MFF115WBM	Bottom Freezer
Marathon	MFF121WLH	Top Freezer
Marathon	MFF122*	Top Freezer
Marathon	MFF122SS	Top Freezer
Marathon	MFF122W	Top Freezer
Marathon	MFF122WLH	Top Freezer
Marathon	MFF179SSBM-LH	Bottom Freezer
Marathon	MFF179SSBM-RH	Bottom Freezer
Marathon	MFF179WBM-LH	Bottom Freezer
Marathon	MFF179WBM-RH	Bottom Freezer
Marathon	MFF180SSFD	Bottom Freezer
Marathon	MFF180SSFD-1	Bottom Freezer
Marathon	MFF180WFD	Bottom Freezer
Marathon	MFF180WFD-1	Bottom Freezer
Marathon	MFF182SS	Top Freezer
Marathon	MFF182W	Top Freezer
Marathon	MFF208SSFD	Bottom Freezer
Marathon	MFF208WFD	Bottom Freezer
Marathon	MFF212*****	Freezerless and Single Door
Marathon	MFF212BLS	Freezerless and Single Door
Maytag	Brand Name: Maytag	Bottom Freezer
Maytag	MB*1957DE*	Bottom Freezer
Maytag	MB*1957DE*	Bottom Freezer
Maytag	MBB1957FE***	Bottom Freezer
Maytag	MBB1957FE***	Bottom Freezer
Maytag	MBF1953DE*	Bottom Freezer
Maytag	MBF1958DE*	Bottom Freezer
Maytag	MBF1958FE***	Bottom Freezer
Maytag	MBF2258DE*	Bottom Freezer
Maytag	MBF2258FE***	Bottom Freezer
Maytag	MBL1957DE*	Bottom Freezer

Maytag	MBL1957FE***	Bottom Freezer
Maytag	MBL1957FE***	Bottom Freezer
Maytag	MBR1957FE***	Bottom Freezer
Maytag	MBR1957FE***	Bottom Freezer
Maytag	MFC2062FE***	Bottom Freezer
Maytag	MFF2258FE*	Bottom Freezer
Maytag	MFF2558FE***	Bottom Freezer
Maytag	MFI2570FE***	Bottom Freezer
Maytag	MFT2574DE*	Bottom Freezer
Maytag	MFT2772HE*0*	Bottom Freezer
Maytag	MFT2776FE***	Bottom Freezer
Maytag	MRFF4136R*	Bottom Freezer
Maytag	MRFF4236R*	Bottom Freezer
Maytag	MRFF4336TZ	Bottom Freezer
Maytag	MRFF5033P*	Bottom Freezer
Maytag	MRFF5036P*	Bottom Freezer
Maytag	MRFF5336TZ	Bottom Freezer
Maytag	MRMF5436TZ	Bottom Freezer
MicroFridge	10.0LMF4R	Top Freezer
MicroFridge	10.0LMF4RW	Top Freezer
MicroFridge	10.0RMF4R	Top Freezer
MicroFridge	10.0RMF4RW	Top Freezer
MicroFridge	10.1MF1R	Top Freezer
Midea	Brand: Midea.	Bottom Freezer
Midea	HC-827WE(SNZ)	Bottom Freezer
Midea	HD-423FW	Top Freezer
Midea	HD-423ST-BKS	Top Freezer
Midea	HD-676FWEN	Bottom Freezer
Midea	HD-774**	Top Freezer
Midea	HD663FWE	Top Freezer
Midea	HQ-827WEN	Bottom Freezer
Midea	HS-507FWEN	Freezerless and Single Door
Midea	MB19ED***#***	Bottom Freezer
Midea	MB19ED***#***	Bottom Freezer
Midea	MDRB697FGE01PRR	Bottom Freezer
Midea	MDRF1100FGF04PRG	Bottom Freezer
Midea	MDRF699FGF04PRR	Bottom Freezer
Midea	MDRF699FGF04PRR	Bottom Freezer
Midea	MDRM648FGF02PRR	Bottom Freezer
Midea	MDRM848FGF04PRR	Bottom Freezer
Midea	MDRT663FGF*****	Top Freezer
Midea	MRB12B1***	Bottom Freezer
Midea	MRB19B5AST	Bottom Freezer
Midea	MRB19B5AST	Bottom Freezer
Midea	MRB19B6***	Bottom Freezer
Midea	MRB19B6***	Bottom Freezer
Midea	MRB19B7***	Bottom Freezer
Midea	MRB19B7***	Bottom Freezer
Midea	MRB19B7A**	Bottom Freezer
Midea	MRB23D5***	Bottom Freezer
Midea	MRF18B4***	Bottom Freezer

Midea	MRF18B4***	Bottom Freezer
Midea	MRF18B4A**	Bottom Freezer
Midea	MRF18B4AST	Bottom Freezer
Midea	MRF18B4AST	Bottom Freezer
Midea	MRF23I5***	Bottom Freezer
Midea	MRF23I7***	Bottom Freezer
Midea	MRF27I6***	Bottom Freezer
Midea	MRF29D2***	Bottom Freezer
Midea	MRF29D3ABB	Bottom Freezer
Midea	MRF29D3AST	Bottom Freezer
Midea	MRF29D3AWW	Bottom Freezer
Midea	MRF29D6AST	Bottom Freezer
Midea	MRF29D9***	Bottom Freezer
Midea	MRF32I6***	Bottom Freezer
Midea	MRQ22D4AST	Bottom Freezer
Midea	MRQ22D5AST	Bottom Freezer
Midea	MRQ22D7AST	Bottom Freezer
Midea	MRQ23B4AST	Bottom Freezer
Midea	MRQ23BCAST	Bottom Freezer
Midea	MRQ23P4A**	Bottom Freezer
Midea	MRQ23P4AST	Bottom Freezer
Midea	MRS25I7B**	Side-by-Side
Midea	MRS26D7AST	Side-by-Side
Midea	MRT12B2A**	Top Freezer
Midea	MRT14B3A**	Top Freezer
Midea	MRT14D2B**	Top Freezer
Midea	MRT14D3B**	Top Freezer
Midea	MRT16D2B**	Top Freezer
Midea	MRT18B2***	Top Freezer
Midea	MRT18D1B**	Top Freezer
Midea	MRT18D2B**	Top Freezer
Midea	MRT18D3B**	Top Freezer
Midea	MRT18D4B**	Top Freezer
Midea	MRT18S2A**	Top Freezer
Midea	MRT18S3A**	Top Freezer
Midea	MRT21D3B**	Top Freezer
Midea	MRU14F5A**	Freezerless and Single Door
Midea	MRU17F6A**	Freezerless and Single Door
Midea	MRU21C7***	Bottom Freezer
Midea	MU170CWBR1RC1	Freezerless and Single Door
Midea	UR-BCD512WX-SQ	Top Freezer
Midea	UR-BCD512WX-SQ-IK	Top Freezer
Midea	WHD-663FWE***	Top Freezer
Midea	WHD-663FWEB1	Top Freezer
Midea	WHD-663FWEB1*	Top Freezer
Midea	WHD-663FWESS1	Top Freezer
Midea	WHD-663FWESS1*	Top Freezer
Midea	WHD-663FWEW1*	Top Freezer
Midea	WHD-774FSSE1	Top Freezer
Midea	WHD-774FW1	Top Freezer
Midea	WHD-774FWE1	Top Freezer

Midea	WHS-625FWESS1	Freezerless and Single Door
Midea	WHS-625FWEW1	Freezerless and Single Door
Miele	K 2602 SF	Freezerless and Single Door
Miele	K 2802 SF	Freezerless and Single Door
Miele	K 2812 SF	Freezerless and Single Door
Miele	K 2902 SF	Freezerless and Single Door
Miele	K 2912 SF	Freezerless and Single Door
Miele	KF 2802 SF	Bottom Freezer
Miele	KF 2812 SF	Bottom Freezer
Miele	KF 2902 SF	Bottom Freezer
Miele	KF 2912 SF	Bottom Freezer
Miele	K 2601 SF	Freezerless and Single Door
Miele	K 2601 Vi	Freezerless and Single Door
Miele	K 2602 Vi	Freezerless and Single Door
Miele	K 2611 Vi	Freezerless and Single Door
Miele	K 2612 Vi	Freezerless and Single Door
Miele	K 2801 SF	Freezerless and Single Door
Miele	K 2801 Vi	Freezerless and Single Door
Miele	K 2802 Vi	Freezerless and Single Door
Miele	K 2811 SF	Freezerless and Single Door
Miele	K 2811 Vi	Freezerless and Single Door
Miele	K 2812 Vi	Freezerless and Single Door
Miele	K 2901 SF	Freezerless and Single Door
Miele	K 2901 Vi	Freezerless and Single Door
Miele	K 2902 Vi	Freezerless and Single Door
Miele	K 2911 SF	Freezerless and Single Door
Miele	K 2911 Vi	Freezerless and Single Door
Miele	K 2912 Vi	Freezerless and Single Door
Miele	KF 2801 SF	Bottom Freezer
Miele	KF 2801 Vi	Bottom Freezer
Miele	KF 2802 Vi	Bottom Freezer
Miele	KF 2811 SF	Bottom Freezer
Miele	KF 2811 Vi	Bottom Freezer
Miele	KF 2812 Vi	Bottom Freezer
Miele	KF 2901 SF	Bottom Freezer
Miele	KF 2901 Vi	Bottom Freezer
Miele	KF 2902 Vi	Bottom Freezer
Miele	KF 2911 SF	Bottom Freezer
Miele	KF 2911 Vi	Bottom Freezer
Miele	KF 2912 Vi	Bottom Freezer
Miele	KF 2981 SF	Bottom Freezer
Miele	KF 2981 Vi	Bottom Freezer
Miele	KF 2982 SF	Bottom Freezer
Miele	KF 2982 Vi	Bottom Freezer
Miele	KFMC 3632 L	Bottom Freezer
Miele	KFMC 3632 R	Bottom Freezer
Miele	KFMC 3642 FD	Bottom Freezer
Miele	KFMC 3642 L	Bottom Freezer
Miele	KFMC 3642 R	Bottom Freezer
Miele	KFMC 3836 L	Bottom Freezer
Miele	KFMC 3836 R	Bottom Freezer

Miele	KFMC 3846 FD	Bottom Freezer
Miele	KFMC 3846 L	Bottom Freezer
Miele	KFMC 3846 R	Bottom Freezer
Miele	KFMC 3858 FD	Bottom Freezer
Miele	KFN 4776 ED edt/cs	Bottom Freezer
Miele	KFN 4799 DDE edt/cs	Bottom Freezer
Miele	KFN 7734 D	Bottom Freezer
Miele	KFN 7795 D	Bottom Freezer
Miele	KFN 9859 iDE li	Bottom Freezer
Miele	KFN 9859 iDE re	Bottom Freezer
Miele	KFNF 9959 iDE	Bottom Freezer
Miele	KI KBM30USM	Bottom Freezer
Miele	KI KBM30USM	Bottom Freezer
Miele	KI KBM30USM	Bottom Freezer
Miele	KI KBM36DUSM	Bottom Freezer
Miele	KI KBM36USM	Bottom Freezer
Miele	KI KBM36USM	Bottom Freezer
Miele	KI KBM36USM	Bottom Freezer
Miele	KI KSDR24USM	Freezerless and Single Door
Miele	KI KSDR24USM	Freezerless and Single Door
Miele	KI KSDR30USM	Freezerless and Single Door
Miele	KI KSDR30USM	Freezerless and Single Door
Miele	KI KSDR30USM	Freezerless and Single Door
Miele	KI KSDR36USM	Freezerless and Single Door
Miele	KI KSDR36USM	Freezerless and Single Door
Miele	KI KSDR36USM	Freezerless and Single Door
Miele	KS 7793 D	Freezerless and Single Door
Miele	KWT 6722 iS	Cooler
Moffat	M2E9*****	Bottom Freezer
Moffat	MBE11D****	Bottom Freezer
Moffat	MBE11DSVSS	Bottom Freezer
Moffat	MBE19D****	Bottom Freezer
Moffat	MBE19D*****	Bottom Freezer
Moffat	MBE19DSNKSS	Bottom Freezer
Moffat	MBE19DTNKWW	Bottom Freezer
Moffat	MDE19D****	Bottom Freezer
Moffat	MDE19D****	Bottom Freezer
Moffat	MDE19D*****	Bottom Freezer
Moffat	MDE19D*****	Bottom Freezer
Moffat	MNE18DYTNFS	Bottom Freezer
Moffat	MNE18DYTNFS	Bottom Freezer
Moffat	MPE12F****	Top Freezer
Moffat	MPE12F*****	Top Freezer
Moffat	MTE18G****	Top Freezer
Moffat	MTE18GSKSS*	Top Freezer
Moffat	MTE18GTKWW*	Top Freezer
Moffat	MTE18HSLSS*	Top Freezer
Moffat	MTE18HSKRSS*	Top Freezer
Moffat	MTE18HTKBB*	Top Freezer
Moffat	MTE18HTKRWW*	Top Freezer
Moffat	MWE22FYPKF*	Bottom Freezer

Moffat	MWE22FYPKFS	Bottom Freezer
Moffat	MYE22HYPKFS	Bottom Freezer
Monogram	ZIC303NPP****	Bottom Freezer
Monogram	ZIC30GNN****	Bottom Freezer
Monogram	ZIC360NN****	Bottom Freezer
Monogram	ZIC360NP****	Bottom Freezer
Monogram	ZIC360NV****	Bottom Freezer
Monogram	ZICS360NN****	Bottom Freezer
Monogram	ZICS360NP****	Bottom Freezer
Monogram	ZICS360NV****	Bottom Freezer
Monogram	ZIR241NBR****	Freezerless and Single Door
Monogram	ZIR241NPN****	Freezerless and Single Door
Monogram	ZIR241NPP****	Freezerless and Single Door
Monogram	ZIR301NBR****	Freezerless and Single Door
Monogram	ZIR301NPN****	Freezerless and Single Door
Monogram	ZIR301NPP****	Freezerless and Single Door
Monogram	ZIR360NN****	Freezerless and Single Door
Monogram	ZIR360NP****	Freezerless and Single Door
Monogram	ZIR361NBR****	Freezerless and Single Door
Monogram	ZIR361NPR****	Freezerless and Single Door
Monogram	ZIRS360NN****	Freezerless and Single Door
Monogram	ZIRS360NP****	Freezerless and Single Door
Monogram	ZIW241NBW****	Cooler
Monogram	ZWE23ESN****	Bottom Freezer
Monogram	ZWE23NST****	Bottom Freezer
Monogram	ZWE23NSY****	Bottom Freezer
Monogram	ZWE23PSN****	Bottom Freezer
Mora	VTH1113YG)	Bottom Freezer
Mora	VTH1113YG)	Bottom Freezer
Mora	MRB148N6A*E	Bottom Freezer
Mora	MRB172N6A*E	Bottom Freezer
Mora	MRB221N6ABE	Bottom Freezer
Mora	MRB221N6ASE	Bottom Freezer
Mora	MRB221N6AWE	Bottom Freezer
Mora	MRB221N6B*E	Bottom Freezer
Mora	MRF206N6BSE	Bottom Freezer
Mora	MRF211N6C**	Bottom Freezer
Mora	MRF211N6C*E	Bottom Freezer
Mora	MRF220N6B*E	Bottom Freezer
Mora	MRF220N6B*EW	Bottom Freezer
Mora	MRF224N6CSE	Bottom Freezer
Mora	MRF266N6C*E	Bottom Freezer
Mora	MRM198N6T*E	Bottom Freezer
Mora	MRM260N6T*E	Bottom Freezer
Mora	MRM260N6T*EW	Bottom Freezer
Mora	MRT115P3AVE	Top Freezer
Nutrifrost	MAUS-NF-FC2-66FS	Top Freezer
OMNImax	3730-739	Freezerless and Single Door
OMNImax	3750-247	Bottom Freezer
OMNImax	3750-247	Bottom Freezer
OMNImax	3760-333	Bottom Freezer

OMNImax	3760-333	Bottom Freezer
OMNImax	3760-675	Bottom Freezer
OMNImax	Icemaker-Ready Product (with icemaker).	Bottom Freezer
OMNImax	Icemaker-Ready Product (without icemaker).	Bottom Freezer
OMNImax	OMB18FDSS	Bottom Freezer
OMNImax	OMB18FDSS	Bottom Freezer
POLAR ELITE	POLRTF18**	Top Freezer
POLAR ELITE	POLRTF18**	Top Freezer
POLAR ELITE	POLRTF18WH	Top Freezer
POLAR ELITE	POLUF21	Freezerless and Single Door
POLAR ELITE	POLUF21WS	Freezerless and Single Door
POLAR ELITE	without ice maker type	Top Freezer
Premium Levella	PFV21206HS	Freezerless and Single Door
Premium Levella	PRN18****	Top Freezer
Premium Levella	PRN20****	Top Freezer
Premium Levella	PRNIM18****	Top Freezer
Premium Levella	PRNIM20****	Top Freezer
Professional Series	PS-FRF172	Bottom Freezer
Professional Series	PS-FRF192	Bottom Freezer
Professional Series	PS-RF262-I6A	Top Freezer
Professional Series	PS-UFR211-I3B	Freezerless and Single Door
QG QUALITY GLOBAL	QGB15C-S	Bottom Freezer
SANKEY	RF 1960 W	Top Freezer
SANKEY	RF 1961 BL	Top Freezer
SANKEY	RF 1963 SS	Top Freezer
SANKEY	RF 2360 W	Top Freezer
SANKEY	RF 2361 BL	Top Freezer
SANKEY	RF 2363 SS	Top Freezer
SMEG Spa	FAB50UXXX	Top Freezer
Samsung	BRB106003**	Bottom Freezer
Samsung	RB10FSR4E**	Bottom Freezer
Samsung	RB12A3006**	Bottom Freezer
Samsung	RB15DG6000**	Bottom Freezer
Samsung	RB16DG6000**	Bottom Freezer
Samsung	RF18A5101**	Bottom Freezer
Samsung	RF20A5101**	Bottom Freezer
Samsung	RF22A4111**	Bottom Freezer
Samsung	RF22A4121**	Bottom Freezer
Samsung	RF22A4221**	Bottom Freezer
Samsung	RF22R7351**	Bottom Freezer
Samsung	RF23A9071**	Bottom Freezer
Samsung	RF23A9671**	Bottom Freezer
Samsung	RF23A9675**	Bottom Freezer
Samsung	RF23A9771**	Bottom Freezer
Samsung	RF23B7671**	Bottom Freezer
Samsung	RF23BB8200**	Bottom Freezer
Samsung	RF23BB8600**	Bottom Freezer
Samsung	RF23BB8900**	Bottom Freezer
Samsung	RF23CB9900**	Bottom Freezer

Samsung	RF23D*9600**	Bottom Freezer
Samsung	RF23DB9700**	Bottom Freezer
Samsung	RF23DB9750**	Bottom Freezer
Samsung	RF23DB9900**	Bottom Freezer
Samsung	RF24BB6200**	Bottom Freezer
Samsung	RF24BB6600**	Bottom Freezer
Samsung	RF24BB6900**	Bottom Freezer
Samsung	RF24R7201**	Bottom Freezer
Samsung	RF25C5151**	Bottom Freezer
Samsung	RF25C5551**	Bottom Freezer
Samsung	RF26CG7400**	Bottom Freezer
Samsung	RF27CG5010**	Bottom Freezer
Samsung	RF27CG5100**	Bottom Freezer
Samsung	RF27CG5400**	Bottom Freezer
Samsung	RF27CG5900**	Bottom Freezer
Samsung	RF27CG5B10**	Bottom Freezer
Samsung	RF27T5201**	Bottom Freezer
Samsung	RF27T5241**	Bottom Freezer
Samsung	RF27T5501**	Bottom Freezer
Samsung	RF28R6201**	Bottom Freezer
Samsung	RF28R6202**	Bottom Freezer
Samsung	RF28R7201**	Bottom Freezer
Samsung	RF28R7351**	Bottom Freezer
Samsung	RF28R7551**	Bottom Freezer
Samsung	RF28T5001**	Bottom Freezer
Samsung	RF28T5021**	Bottom Freezer
Samsung	RF28T5101**	Bottom Freezer
Samsung	RF28T5A01**	Bottom Freezer
Samsung	RF28T5F01**	Bottom Freezer
Samsung	RF29A9071**	Bottom Freezer
Samsung	RF29A9671**	Bottom Freezer
Samsung	RF29A9675**	Bottom Freezer
Samsung	RF29A9771**	Bottom Freezer
Samsung	RF29BB8200**	Bottom Freezer
Samsung	RF29BB8600**	Bottom Freezer
Samsung	RF29BB8900**	Bottom Freezer
Samsung	RF29CB9900**	Bottom Freezer
Samsung	RF29DB9600**	Bottom Freezer
Samsung	RF29DB9700**	Bottom Freezer
Samsung	RF29DB9750**	Bottom Freezer
Samsung	RF29DB9900**	Bottom Freezer
Samsung	RF30BB6200**	Bottom Freezer
Samsung	RF30BB6600**	Bottom Freezer
Samsung	RF30BB6602**	Bottom Freezer
Samsung	RF30BB6900**	Bottom Freezer
Samsung	RF31CG7200**	Bottom Freezer
Samsung	RF31CG7220**	Bottom Freezer
Samsung	RF31CG7400**	Bottom Freezer
Samsung	RF32CG5100**	Bottom Freezer
Samsung	RF32CG5300**	Bottom Freezer
Samsung	RF32CG5400**	Bottom Freezer

Samsung	RF32CG5900**	Bottom Freezer
Samsung	RF32CG5B10**	Bottom Freezer
Samsung	RF32CG5N10**	Bottom Freezer
Samsung	RF70F23DE*	Bottom Freezer
Samsung	RF70F29DE*	Bottom Freezer
Samsung	RF90F23AE*	Bottom Freezer
Samsung	RF90F23AE**	Bottom Freezer
Samsung	RF90F23BE**	Bottom Freezer
Samsung	RF90F29AE*	Bottom Freezer
Samsung	RF90F29AE**	Bottom Freezer
Samsung	RF90F29BE**	Bottom Freezer
Samsung	RM70F22NE*	Bottom Freezer
Samsung	RM80F22WE*	Bottom Freezer
Samsung	RM80F23VM*	Bottom Freezer
Samsung	RQ48T94*2**	Bottom Freezer
Samsung	RR14T7414**	Freezerless and Single Door
Samsung	RS22T5201**	Side-by-Side
Samsung	RS22T5561**	Side-by-Side
Samsung	RS23CB7600**	Side-by-Side
Samsung	RS27T5201**	Side-by-Side
Samsung	RS27T5202**	Side-by-Side
Samsung	RS27T5561**	Side-by-Side
Samsung	RS28A5F61**	Side-by-Side
Samsung	RS28CB7600**	Side-by-Side
Samsung	RT16A6105**	Top Freezer
Samsung	RT16A6195**	Top Freezer
Samsung	RT16A6195**	Top Freezer
Samsung	RT18DG6300**	Top Freezer
Samsung	RT18DG6500**	Top Freezer
Samsung	RT18DG6500**	Top Freezer
Samsung	RT18DG6700**	Top Freezer
Samsung	RT18M62*3**	Top Freezer
Samsung	RT18M62*3**	Top Freezer
Samsung	RT18M62*5**	Top Freezer
Samsung	RT21M62*3**	Top Freezer
Samsung	RT21M62*3**	Top Freezer
Samsung	RT21M62*5**	Top Freezer
Samsung	RT70F18LA**	Top Freezer
Samsung	RT70F18LR**	Top Freezer
Samsung	RT70F18LR**	Top Freezer
Savalo	Employ compressor VTB1113Y	Bottom Freezer
Savalo	SCFR500P30SS	Bottom Freezer
Seasons	to represent different in unit color	Bottom Freezer
Seasons	MSBF18****	Bottom Freezer
Seasons	MSBF18****	Bottom Freezer
Seasons	MSBF18**IM	Bottom Freezer
Seasons	MSFDR18IM	Bottom Freezer
Seasons	MSFDR18IM	Bottom Freezer
Seasons	MSTF10**ES4	Top Freezer

Seasons	MSTF14***	Top Freezer
Seasons	MSTF16**R	Top Freezer
Seasons	MSTF18***	Top Freezer
Seasons	MSTF18****	Top Freezer
Seasons	MSTF18BKR	Top Freezer
Seasons	MSTF18BKR5	Top Freezer
Seasons	MSTF18SSR	Top Freezer
Seasons	MSTF18SSR5	Top Freezer
Seasons	MSTF18WHR	Top Freezer
Seasons	MSTF18WHR5	Top Freezer
Seasons	STMR183**#*	Top Freezer
Sharp	SJB1255GS	Bottom Freezer
Sharp	SJF2955KS	Bottom Freezer
Sharp	SJG2254FS	Bottom Freezer
Sharp	SJG2351FS	Bottom Freezer
Sharp	SJG2351FS	Bottom Freezer
Signature Kitchen Suite	SKSCR2401*	Freezerless and Single Door
Signature Kitchen Suite	SKSCR3001*	Freezerless and Single Door
Signature Kitchen Suite	SKSCW181**	Cooler
Signature Kitchen Suite	SKSCW241**	Cooler
Signature Kitchen Suite	SKSFD3604*	Bottom Freezer
Signature Kitchen Suite	SKSFD3613*	Bottom Freezer
Signature Kitchen Suite	SKSFD3623*D	Bottom Freezer
Signature Kitchen Suite	SKSFD4826*	Bottom Freezer
Signature Kitchen Suite	SKSFD4826**	Bottom Freezer
Signature Kitchen Suite	SKSSB4202*	Side-by-Side
Smad	can be any letter or blank	Bottom Freezer
Smad	can be any letter or blank	Bottom Freezer
Smad	DDB-676WMU	Bottom Freezer
Smad	DDB-676WMU	Bottom Freezer
Smad	DDT-423WMU (U)	Top Freezer
Smad	DDT-510W*A1U	Top Freezer
Smad	DDT-517WMU	Top Freezer
Smad	DDT-517WSMU	Top Freezer
Smad	DDT-663W***	Top Freezer
Smad	DDT-744WMU	Top Freezer
Smad	DM-607W*3U(l)	Bottom Freezer
Smad	DM-644W*3U(l)	Bottom Freezer
Smad	DM-827WMU	Bottom Freezer
Smad	DSD-625WMU	Freezerless and Single Door
Smeg	BM30URXI	Bottom Freezer
Smeg	CB300U	Bottom Freezer
Smeg	FA490Uxxx	Bottom Freezer
Smeg	FAB28UL*#	Freezerless and Single Door
Smeg	FAB28UR*#	Freezerless and Single Door
Smeg	FAB32UL*#	Bottom Freezer
Smeg	FAB32UR*#	Bottom Freezer
Smeg	FAB38Uxxx	Bottom Freezer
Smeg	FD30UXI	Bottom Freezer
Smeg	FD36UXIW	Bottom Freezer
Smeg	FQ55UFX	Bottom Freezer

Smeg	FTU171*7	Bottom Freezer
Smeg	FTU171X7	Bottom Freezer
Sub-Zero	CL3050U**/S/*/*	Bottom Freezer
Sub-Zero	CL3650R**/S/*/*	Freezerless and Single Door
Sub-Zero	CL3650U**/S/*/*	Bottom Freezer
Sub-Zero	CL4250UFD**/S/*	Bottom Freezer
Sub-Zero	CL4850S/S/*	Side-by-Side
Sub-Zero	DEC1850FI/*	Upright Freezer
Sub-Zero	DEC2450R/*	Freezerless and Single Door
Sub-Zero	DEC3050R**/*	Freezerless and Single Door
Sub-Zero	DEC3650R**/*	Freezerless and Single Door
Sub-Zero	DET3050CI**/*	Bottom Freezer
Sub-Zero	DET3050R**/*	Freezerless and Single Door
Sub-Zero	DET3650CI**/*	Bottom Freezer
Sub-Zero	DET3650R**/*	Freezerless and Single Door
Summit	BF181SS	Bottom Freezer
Summit	BF249SS	Bottom Freezer
Summit	CTR151W	Top Freezer
Summit	CTR152B	Top Freezer
Summit	CTR153PL	Top Freezer
Summit	CTR15SS	Top Freezer
Summit	CTR18**	Top Freezer
Summit	CTR21PL	Top Freezer
Summit	CTR21W	Top Freezer
Summit	FDRD15SS	Bottom Freezer
Summit	FF108****	Top Freezer
Summit	FF1087B	Top Freezer
Summit	FF1088*	Top Freezer
Summit	FF1089**	Top Freezer
Summit	FF1141W	Bottom Freezer
Summit	FF1142PL	Top Freezer
Summit	FF1511SS	Top Freezer
Summit	FF1512SSIM	Top Freezer
Summit	FF1515W	Top Freezer
Summit	FF156B	Top Freezer
Summit	FF156PL	Top Freezer
Summit	FF156SS	Top Freezer
Summit	FF156W	Top Freezer
Summit	FFBF121W	Bottom Freezer
Summit	FFBF122PL	Bottom Freezer
Summit	FFBF123B	Bottom Freezer
Summit	FFBF124SS	Bottom Freezer
Summit	FFBF151W	Bottom Freezer
Summit	FFBF152PL	Bottom Freezer
Summit	FFBF153B	Bottom Freezer
Summit	FFBF154SS	Bottom Freezer
Summit	FFBF181ES	Bottom Freezer
Summit	FFBF181ES2	Bottom Freezer
Summit	FFBF235PL	Bottom Freezer
Summit	FFBF241W	Bottom Freezer
Summit	FFBF247SSIM	Bottom Freezer

Summit	FFBF249SS	Bottom Freezer
Summit	FFBF249SS2	Bottom Freezer
Summit	FFBF279SS	Bottom Freezer
Summit	FFBF279SSX	Bottom Freezer
Summit	FFBF281W	Bottom Freezer
Summit	FFBF283SS	Bottom Freezer
Summit	FFBF284SSIM	Bottom Freezer
Summit	LBF12B	Bottom Freezer
Summit	LBF12PL	Bottom Freezer
Summit	LBF12SS	Bottom Freezer
Summit	LBF12W	Bottom Freezer
Summit	LBF16B	Bottom Freezer
Summit	LBF16PL	Bottom Freezer
Summit	LBF16SS	Bottom Freezer
Summit	LBF16W	Bottom Freezer
Summit	LBF181	Bottom Freezer
Summit	LBF249	Bottom Freezer
Summit	LRF108****	Top Freezer
Summit	LRF1087B	Top Freezer
Summit	LRF1088*	Top Freezer
Summit	LRF1089**	Top Freezer
Summit	LRF15B	Top Freezer
Summit	LRF15PL	Top Freezer
Summit	LRF15SS	Top Freezer
Summit	LRF15W	Top Freezer
Summit	SBF125B	Bottom Freezer
Summit	SBF125SS	Bottom Freezer
Summit	SBF125W	Bottom Freezer
Summit	SBF126PL	Bottom Freezer
Summit	SBF16B	Bottom Freezer
Summit	SBF16PL	Bottom Freezer
Summit	SBF16SS	Bottom Freezer
Summit	SBF16W	Bottom Freezer
Summit;Dreambilt	DBINTRF11	Bottom Freezer
Summit;Dreambilt	FFBF11NT	Bottom Freezer
THOR KITCHEN	BCD-606WHI	Side-by-Side
THOR KITCHEN	RF3016BBP	Bottom Freezer
THOR KITCHEN	RF3017FFD00	Bottom Freezer
THOR KITCHEN	RF3017FFD99	Bottom Freezer
THOR KITCHEN	RF3619BFP	Bottom Freezer
THOR KITCHEN	RF3621CTD00	Bottom Freezer
THOR KITCHEN	RF3621CTD99	Bottom Freezer
THOR KITCHEN	TRF3602	Bottom Freezer
THOR KITCHEN	TRF3628FFD	Bottom Freezer
THOR KITCHEN	TRF3628FFDB	Bottom Freezer
THOR KITCHEN	XRF3016BBP	Bottom Freezer
THOR KITCHEN	XRF3619BFP	Bottom Freezer
THORKITCHEN	TRF3601FD	Bottom Freezer
THORKITCHEN	XRF24CRF	Freezerless and Single Door
THORKITCHEN	XRF30CRF	Freezerless and Single Door
Thermador	T30BB920SS	Bottom Freezer

Thermador	T30BB925SS	Bottom Freezer
Thermador	T36BB920SS	Bottom Freezer
Thermador	T36BB925SS	Bottom Freezer
Thermador	T36BT915NS	Bottom Freezer
Thermador	T36BT920NS	Bottom Freezer
Thermador	T36BT925NS	Bottom Freezer
Thermador	T23IR900SP	Freezerless and Single Door
Thermador	T23IR905SP	Freezerless and Single Door
Thermador	T24IR800SP	Freezerless and Single Door
Thermador	T24IR900SP	Freezerless and Single Door
Thermador	T24IR902SP	Freezerless and Single Door
Thermador	T24IR905SP	Freezerless and Single Door
Thermador	T30BB910SS	Bottom Freezer
Thermador	T30BB915SS	Bottom Freezer
Thermador	T30IB100SP	Bottom Freezer
Thermador	T30IB900SP	Bottom Freezer
Thermador	T30IB905SP	Bottom Freezer
Thermador	T30IR900SP	Freezerless and Single Door
Thermador	T30IR901SP	Freezerless and Single Door
Thermador	T30IR902SP	Freezerless and Single Door
Thermador	T30IR905SP	Freezerless and Single Door
Thermador	T36BB110SS	Bottom Freezer
Thermador	T36BB120SS	Bottom Freezer
Thermador	T36BB910SS	Bottom Freezer
Thermador	T36BB915SS	Bottom Freezer
Thermador	T36BT110NS	Bottom Freezer
Thermador	T36BT120NS	Bottom Freezer
Thermador	T36BT910NS	Bottom Freezer
Thermador	T36FL810NS	Bottom Freezer
Thermador	T36FL821NS	Bottom Freezer
Thermador	T36FT810N*	Bottom Freezer
Thermador	T36FT820N*	Bottom Freezer
Thermador	T36IB100SP	Bottom Freezer
Thermador	T36IB900SP	Bottom Freezer
Thermador	T36IB902SP	Bottom Freezer
Thermador	T36IB905SP	Bottom Freezer
Thermador	T36IR900SP	Freezerless and Single Door
Thermador	T36IR905SP	Freezerless and Single Door
Thermador	T36IT100NP	Bottom Freezer
Thermador	T36IT900NP	Bottom Freezer
Thermador	T36IT901NP	Bottom Freezer
Thermador	T36IT902NP	Bottom Freezer
Thermador	T36IT903NP	Bottom Freezer
Thermador	T36IT905NP	Bottom Freezer
Thermador	T42BT110NS	Bottom Freezer
Thermador	T42BT120NS	Bottom Freezer
Thermador	T42IT100NP	Bottom Freezer
Thermador	T48BT110NS	Bottom Freezer
Thermador	T48BT120NS	Bottom Freezer
Thermador	T48IT100NP	Bottom Freezer
Toscana	FD225BSS	Bottom Freezer

Toscana	FD225SS	Bottom Freezer
UNIQUE	UGP-275L 1 W AC	Freezerless and Single Door
UNIQUE	UGP-275L AO AC	Freezerless and Single Door
UNIQUE	UGP-275L B AC	Freezerless and Single Door
UNIQUE	UGP-275L BP AC	Freezerless and Single Door
UNIQUE	UGP-275L C AC	Freezerless and Single Door
UNIQUE	UGP-275L LB AC	Freezerless and Single Door
UNIQUE	UGP-275L LG AC	Freezerless and Single Door
UNIQUE	UGP-275L R AC	Freezerless and Single Door
UNIQUE	UGP-275L RB AC	Freezerless and Single Door
UNIQUE	UGP-275L SC AC	Freezerless and Single Door
UNIQUE	UGP-275L SP AC	Freezerless and Single Door
UNIQUE	UGP-275L T AC	Freezerless and Single Door
UNIQUE	UGP-275L W AC	Freezerless and Single Door
UNIQUE	UGP-275L WR AC	Freezerless and Single Door
UNIQUE	UGP-278L P B	Freezerless and Single Door
UNIQUE	UGP-278L P S/S	Freezerless and Single Door
UNIQUE	UGP-278L P W	Freezerless and Single Door
UNIQUE	UGP-328L P B	Bottom Freezer
UNIQUE	UGP-328L P S/S	Bottom Freezer
UNIQUE	UGP-328L P W	Bottom Freezer
UNIQUE	UGP-330L AO AC	Bottom Freezer
UNIQUE	UGP-330L B AC	Bottom Freezer
UNIQUE	UGP-330L BP AC	Bottom Freezer
UNIQUE	UGP-330L LB AC	Bottom Freezer
UNIQUE	UGP-330L LG AC	Bottom Freezer
UNIQUE	UGP-330L R AC	Bottom Freezer
UNIQUE	UGP-330L RB AC	Bottom Freezer
UNIQUE	UGP-330L SC AC	Bottom Freezer
UNIQUE	UGP-330L SP AC	Bottom Freezer
UNIQUE	UGP-330L T AC	Bottom Freezer
UNIQUE	UGP-330L W AC	Bottom Freezer
UNIQUE	UGP-340L B AC	Bottom Freezer
UNIQUE	UGP-340L LG AC	Bottom Freezer
UNIQUE	UGP-340L MB AC	Bottom Freezer
UNIQUE	UGP-340L O AC	Bottom Freezer
UNIQUE	UGP-340L T AC	Bottom Freezer
UNIQUE	UGP-340L W AC	Bottom Freezer
UNIQUE	UGP-340L Y AC	Bottom Freezer
UNIQUE	UGP-510L B AC	Bottom Freezer
UNIQUE	UGP-510L LG AC	Bottom Freezer
UNIQUE	UGP-510L T AC	Bottom Freezer
UNIQUE	UGP-510L W AC	Bottom Freezer
UNIQUE	UGP-595L B AC	Bottom Freezer
UNIQUE	UGP-595L LG AC	Bottom Freezer
UNIQUE	UGP-595L T AC	Bottom Freezer
UNIQUE	UGP-595L W AC	Bottom Freezer
UNIQUE	UNQ-310L B TM	Top Freezer
UNIQUE	UNQ-310L LG TM	Top Freezer
UNIQUE	UNQ-310L MB TM	Top Freezer
UNIQUE	UNQ-310L O TM	Top Freezer

UNIQUE	UNQ-310L R TM	Top Freezer
UNIQUE	UNQ-310L T TM	Top Freezer
UNIQUE	UNQ-310L W TM	Top Freezer
UNIQUE	UNQ-310L Y TM	Top Freezer
UNIQUE	UNQ-455L B AC	Bottom Freezer
UNIQUE	UNQ-455L LG AC	Bottom Freezer
UNIQUE	UNQ-455L MB AC	Bottom Freezer
UNIQUE	UNQ-455L O AC	Bottom Freezer
UNIQUE	UNQ-455L R AC	Bottom Freezer
UNIQUE	UNQ-455L T AC	Bottom Freezer
UNIQUE	UNQ-455L W AC	Bottom Freezer
UNIQUE	UNQ-455L Y AC	Bottom Freezer
VIKING	CFRI7240****	Freezerless and Single Door
VIKING	CFRI7300****	Freezerless and Single Door
VIKING	CFRI7360****	Freezerless and Single Door
VIKING	CMVRI7240****	Freezerless and Single Door
VIKING	CMVRI7300****	Freezerless and Single Door
VIKING	CMVRI7360****	Freezerless and Single Door
VIKING	CVRI7240****	Freezerless and Single Door
VIKING	CVRI7300****	Freezerless and Single Door
VIKING	CVRI7360****	Freezerless and Single Door
VIKING	FBI7360****	Bottom Freezer
VIKING	FDSB5423*****	Side-by-Side
VIKING	FDSB5483*****	Side-by-Side
VIKING	FRI7240****	Freezerless and Single Door
VIKING	FRI7300****	Freezerless and Single Door
VIKING	FRI7360****	Freezerless and Single Door
VIKING	MVBI7360****	Bottom Freezer
VIKING	MVRI7240****	Freezerless and Single Door
VIKING	MVRI7300****	Freezerless and Single Door
VIKING	MVRI7360****	Freezerless and Single Door
VIKING	VBI7360****	Bottom Freezer
VIKING	VCSB5423*****	Side-by-Side
VIKING	VCSB5483*****	Side-by-Side
VIKING	VRI7240****	Freezerless and Single Door
VIKING	VRI7300****	Freezerless and Single Door
VIKING	VRI7360****	Freezerless and Single Door
VIKING RANGE LLC	RVFFR336SS	Bottom Freezer
VITARA	B for black	Top Freezer
VITARA	B for black	Top Freezer
VITARA	S for stainless finish	Top Freezer
VITARA	S for stainless finish	Top Freezer
VITARA	* means color	Top Freezer
VITARA	* means color	Top Freezer
VITARA	Employ compressor VFL090CY1	Bottom Freezer
VITARA	Employ compressor VFL090CY1	Bottom Freezer
VITARA	Employ compressor VFL090CY1	Bottom Freezer

VITARA	Employ compressor VFL090CY1	Bottom Freezer
VITARA	Employ compressor VFL100CY1	Bottom Freezer
VITARA	Employ compressor VFL100CY1	Bottom Freezer
VITARA	VBBM0840EWEI	Bottom Freezer
VITARA	VBBM1200EWEI	Bottom Freezer
VITARA	VBCF0860EWEI	Freezerless and Single Door
VITARA	VBCR1201EWE	Freezerless and Single Door
VITARA	VBCR1661EWE	Freezerless and Single Door
VITARA	VBFR1150ESE	Bottom Freezer
VITARA	VBFR1200EISE	Bottom Freezer
VITARA	VBFR1200EISSE	Bottom Freezer
VITARA	VBFR1200ESE	Bottom Freezer
VITARA	VBFR1200ESSE	Bottom Freezer
VITARA	VBFR1500ESSE	Bottom Freezer
VITARA	VBFR1800EBE	Bottom Freezer
VITARA	VBFR1800ESE	Bottom Freezer
VITARA	VBFR1800ESE-C	Bottom Freezer
VITARA	VBFR1800ESSE	Bottom Freezer
VITARA	VBFR1800ESSE-C	Bottom Freezer
VITARA	VBFR1800EWE	Bottom Freezer
VITARA	VFFR1700ESBE	Bottom Freezer
VITARA	VFFR1700ESE	Bottom Freezer
VITARA	VFFR1700ESSE	Bottom Freezer
VITARA	VFFR1800EBE	Bottom Freezer
VITARA	VFFR1800ESBE	Bottom Freezer
VITARA	VFFR1800ESE	Bottom Freezer
VITARA	VFFR1800ESSE	Bottom Freezer
VITARA	VFFR1800ESSE-C	Bottom Freezer
VITARA	VFFR1800EWE	Bottom Freezer
VITARA	VFFR1801ESBE	Bottom Freezer
VITARA	VFFR1801ESE	Bottom Freezer
VITARA	VFFR1801ESSE	Bottom Freezer
VITARA	VFFR2100ESSE	Bottom Freezer
VITARA	VFFR2101EBE	Bottom Freezer
VITARA	VFFR2101ESBE	Bottom Freezer
VITARA	VFFR2101ESBE-C	Bottom Freezer
VITARA	VFFR2101ESE	Bottom Freezer
VITARA	VFFR2101ESE-C	Bottom Freezer
VITARA	VFFR2101ESSE	Bottom Freezer
VITARA	VFFR2101ESSE-C	Bottom Freezer
VITARA	VFFR2101EWE	Bottom Freezer
VITARA	VLUF1101EBE	Freezerless and Single Door
VITARA	VLUF1101ESE	Freezerless and Single Door
VITARA	VLUF1101EWE	Freezerless and Single Door
VITARA	VLUF2100E*E	Freezerless and Single Door
VITARA	VLUF2100ESE	Freezerless and Single Door
VITARA	VLUF2100EWE	Freezerless and Single Door
VITARA	VSBS2001EB	Side-by-Side

VITARA	VSBS2001ES	Side-by-Side
VITARA	VSBS2001ESS	Side-by-Side
VITARA	VSBS2001EW	Side-by-Side
VITARA	VTFR1001***	Top Freezer
VITARA	VTFR1001EBE	Top Freezer
VITARA	VTFR1001ESE	Top Freezer
VITARA	VTFR1001EWE	Top Freezer
VITARA	VTFR1201***	Top Freezer
VITARA	VTFR1201EBE	Top Freezer
VITARA	VTFR1201ESE	Top Freezer
VITARA	VTFR1201EWE	Top Freezer
VITARA	VTFR1202EBE	Top Freezer
VITARA	VTFR1202ESE	Top Freezer
VITARA	VTFR1202EWE	Top Freezer
VITARA	VTFR1800***	Top Freezer
VITARA	VTFR1800E**	Top Freezer
VITARA	VTFR1800EBE	Top Freezer
VITARA	VTFR1802EI*E	Top Freezer
VITARA	VTFR1803EBE	Top Freezer
VITARA	VTFR1803ESE	Top Freezer
VITARA	VTFR1803EWE	Top Freezer
VITARA	VTFR2101EI*E	Top Freezer
VITARA	VTFR2102EBE	Top Freezer
VITARA	VTFR2102ESE	Top Freezer
VITARA	VTFR2102EWE	Top Freezer
VITARA	VTFR2400EBE	Top Freezer
VITARA	VTFR2400ESE	Top Freezer
VITARA	VTFR2400ESS	Top Freezer
VITARA	VTFR2400EWE	Top Freezer
VITARA;FORTE	F15TFRAESBB	Top Freezer
VITARA;FORTE	F15TFRAESSS	Top Freezer
VITARA;FORTE	F15TFRAESWW	Top Freezer
VITARA;FORTE	VTFR1500EBE	Top Freezer
VITARA;FORTE	VTFR1500ESE	Top Freezer
VITARA;FORTE	VTFR1500EWE	Top Freezer
VITARA;FORTÉ	F10TFRAESBB	Top Freezer
VITARA;FORTÉ	F10TFRAESSS	Top Freezer
VITARA;FORTÉ	F10TFRAESWW	Top Freezer
VITARA;FORTÉ	VTFR1002EBE	Top Freezer
VITARA;FORTÉ	VTFR1002ESE	Top Freezer
VITARA;FORTÉ	VTFR1002EWE	Top Freezer
Vezeni	Employ compressor VFL090CY1	Bottom Freezer
Vezeni	Employ compressor VFL100CY1	Bottom Freezer
Vezeni	VFS100-SS	Bottom Freezer
Vezeni	VFS101-SS	Bottom Freezer
Vissani	HVDR1000WF	Top Freezer
Vissani	HVUF11SL	Freezerless and Single Door
Vissani	HVUF11SLF	Freezerless and Single Door

Vissani	Icemaker-Ready Product (with icemaker)	Top Freezer
Vissani	Icemaker-Ready Product (with icemaker)	Bottom Freezer
Vissani	Icemaker-Ready Product (without icemaker)	Bottom Freezer
Vissani	Icemaker-Ready Product (without icemaker)	Top Freezer
Vissani	MDBF18SS	Bottom Freezer
Vissani	MDBF18SS	Bottom Freezer
Vissani	MDFD18SS5	Bottom Freezer
Vissani	MDFD18SS5	Bottom Freezer
Vissani	MDTF10**ES4	Top Freezer
Vissani	MDTF12**	Top Freezer
Vissani	MDTF14***	Top Freezer
Vissani	MDTF18****	Top Freezer
Vissani	MDTF18SS	Top Freezer
Vissani	MDTF18SSR	Top Freezer
Vissani	MDTF18SSR	Top Freezer
Vissani	MDTF18SSR*	Top Freezer
Vissani	MDTF18SSR5	Top Freezer
Vissani	MDTF18SSRPRO*	Top Freezer
Vissani	MDTF18WHR5	Top Freezer
Vissani	MDTF18WHRES4	Top Freezer
Vissani	MDTF18WHSRPRO*	Top Freezer
Vissani	VSF11US2A16	Freezerless and Single Door
Vissani	VSF16UWEE16	Freezerless and Single Door
West Bend	WBFF24VDLJM#**	Top Freezer
Westbend	WBFF18DLJ#**	Top Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	Brand Name: Whirlpool	Bottom Freezer
Whirlpool	CB345W	Bottom Freezer
Whirlpool	URB551WNGZ	Bottom Freezer
Whirlpool	URBC5024PZ	Bottom Freezer
Whirlpool	WRB119WFB*	Bottom Freezer
Whirlpool	WRB119WFB*	Bottom Freezer
Whirlpool	WRB322DMB	Bottom Freezer
Whirlpool	WRB322DMH*	Bottom Freezer
Whirlpool	WRB329*FB*	Bottom Freezer
Whirlpool	WRB329*FB*	Bottom Freezer
Whirlpool	WRB329DMB*	Bottom Freezer
Whirlpool	WRB533CZJ***	Bottom Freezer
Whirlpool	WRB533CZJ***	Bottom Freezer
Whirlpool	WRB543CMJ***	Bottom Freezer
Whirlpool	WRB551WNBS	Bottom Freezer
Whirlpool	WRF532SMB*	Bottom Freezer
Whirlpool	WRF532SMH*	Bottom Freezer

Whirlpool	WRF532SNB*	Bottom Freezer
Whirlpool	WRF532SNB*	Bottom Freezer
Whirlpool	WRF532SNH*	Bottom Freezer
Whirlpool	WRF532SNH*	Bottom Freezer
Whirlpool	WRF535SMB*	Bottom Freezer
Whirlpool	WRF535SMH*	Bottom Freezer
Whirlpool	WRF535SWB*	Bottom Freezer
Whirlpool	WRF535SWH*	Bottom Freezer
Whirlpool	WRF540CWB*	Bottom Freezer
Whirlpool	WRF540CWH*	Bottom Freezer
Whirlpool	WRF555SDF***	Bottom Freezer
Whirlpool	WRF555SDH*	Bottom Freezer
Whirlpool	WRF736SDA*	Bottom Freezer
Whirlpool	WRF757SDE***	Bottom Freezer
Whirlpool	WRF757SDH*0*	Bottom Freezer
Whirlpool	WRF767SDE***	Bottom Freezer
Whirlpool	WRF767SDH*0*	Bottom Freezer
Whirlpool	WRF9*4CIH***	Bottom Freezer
Whirlpool	WRF954CIH***	Bottom Freezer
Whirlpool	WRF992FIF***	Bottom Freezer
Whirlpool	WRF993FIF***	Bottom Freezer
Whirlpool	WRF995FIF***	Bottom Freezer
Whirlpool	WRFA32SMH*	Bottom Freezer
Whirlpool	WRFA35SWH*	Bottom Freezer
Whirlpool	WRFC2036R*	Bottom Freezer
Whirlpool	WRFC3036R***	Bottom Freezer
Whirlpool	WRFC5236R***	Bottom Freezer
Whirlpool	WRFC7036R***	Bottom Freezer
Whirlpool	WRFF3036R*	Bottom Freezer
Whirlpool	WRFF3136SB	Bottom Freezer
Whirlpool	WRFF3136SW	Bottom Freezer
Whirlpool	WRFF3136SZ	Bottom Freezer
Whirlpool	WRFF3236R*	Bottom Freezer
Whirlpool	WRFF3336SB	Bottom Freezer
Whirlpool	WRFF3336SW	Bottom Freezer
Whirlpool	WRFF3336SZ	Bottom Freezer
Whirlpool	WRFF3436R*	Bottom Freezer
Whirlpool	WRFF3536SV	Bottom Freezer
Whirlpool	WRFF3536SW	Bottom Freezer
Whirlpool	WRFF3536SZ	Bottom Freezer
Whirlpool	WRFF3736SV	Bottom Freezer
Whirlpool	WRFF3736SW	Bottom Freezer
Whirlpool	WRFF3736SZ	Bottom Freezer
Whirlpool	WRFF5333P*	Bottom Freezer
Whirlpool	WRMF3336SV	Bottom Freezer
Whirlpool	WRMF3336SW	Bottom Freezer
Whirlpool	WRMF3336SZ	Bottom Freezer
Whirlpool	WRMF3536SV	Bottom Freezer
Whirlpool	WRMF3536SW	Bottom Freezer
Whirlpool	WRMF3536SZ	Bottom Freezer
Whirlpool	WRMF3636R*	Bottom Freezer

Whirlpool	WRMF3636SV	Bottom Freezer
Whirlpool	WRMF3636SW	Bottom Freezer
Whirlpool	WRMF3636SZ	Bottom Freezer
Whirlpool	WRMF3736SV	Bottom Freezer
Whirlpool	WRMF3736SW	Bottom Freezer
Whirlpool	WRMF3736SZ	Bottom Freezer
Whirlpool	WRQA59CNKZ	Bottom Freezer
Whirlpool	WRQC7836R*	Bottom Freezer
Whirlpool	WRR56X18F***	Freezerless and Single Door
Whirlpool	WRS331FDD*0*	Side-by-Side
Whirlpool	WRS331SDH*0*	Side-by-Side
Whirlpool	WRS335FDD***	Side-by-Side
Whirlpool	WRS335SDH*0*	Side-by-Side
Whirlpool	WRS586FIE***	Side-by-Side
Whirlpool	WRS586FLD*	Side-by-Side
Whirlpool	WRS975SID***	Side-by-Side
Whirlpool	WRT134TFD*0*	Top Freezer
Whirlpool	WRT134TFD*0*	Top Freezer
Whirlpool	WRT138FFD*	Top Freezer
Whirlpool	WRT138FFD*	Top Freezer
Whirlpool	WRT138FZD*	Top Freezer
Whirlpool	WRT138FZD*	Top Freezer
Whirlpool	WRT148FZD*	Top Freezer
Whirlpool	WRT148FZD*	Top Freezer
Whirlpool	WRT312CZJ***	Top Freezer
Whirlpool	WRT312CZJ***	Top Freezer
Whirlpool	WRT348FME*0*	Top Freezer
Whirlpool	WRT541SZD*0*	Top Freezer
Whirlpool	WRT541SZD*0*	Top Freezer
Whirlpool	WRT541SZH*0*	Top Freezer
Whirlpool	WRT541SZH*0*	Top Freezer
Whirlpool	WRT549SZD*	Top Freezer
Whirlpool	WRT549SZD*	Top Freezer
Whirlpool	WRTX5328P***	Top Freezer
Whirlpool	WRX735SDH*	Bottom Freezer
Wizard by Crosley	WRFE18M4A*	Bottom Freezer
Wizard by Crosley	WRFE18M4A*	Bottom Freezer
Wood's	WFF100B	Top Freezer
Wood's	WFF100S	Top Freezer
Wood's	WFF100SL	Top Freezer
Wood's	WFF100W	Top Freezer
Wood's	WFF180B	Top Freezer
Wood's	WFF180S	Top Freezer
Wood's	WFF180SL	Top Freezer
Wood's	WFF180W	Top Freezer
XO	XOU2470WGS*	Cooler
ZGA	ZRT10ASLOPR	Top Freezer
ZGA	ZRT15ASLOPR	Top Freezer
ZGA	ZRT18ASLOPR	Top Freezer
ZGA	ZRT25ASLOPR	Top Freezer
ZLINE, HALLMAN, SAVALO	HRBIBM30PR	Bottom Freezer

ZLINE, HALLMAN, SAVALO	RBIV-30	Bottom Freezer
ZLINE, HALLMAN, SAVALO	S30BFR700IMBIP	Bottom Freezer
Zephyr	PRW24F01CG	Cooler
Zephyr	PRW24F02CG	Cooler
Zephyr	PRW24F02CPG	Cooler
Zline	Brand: ZLINE.	Bottom Freezer
Zline	Brand: ZLINE.	Bottom Freezer
Zline	RBCRV-24	Freezerless and Single Door
Zline	RBCRV-30	Freezerless and Single Door
Zline	RBIT-36	Bottom Freezer
Zline	RBIV-36*	Bottom Freezer
Zline	RFM-36	Bottom Freezer
Zline	RFM-36-BS	Bottom Freezer
Zline	RFM-W-36	Bottom Freezer
Zline	RFM-W-36-BS	Bottom Freezer
Zline	RSM-W-36	Bottom Freezer
Zline	RSM-W-36-BS	Bottom Freezer
Zline	SRBIV-36	Bottom Freezer
iceBlue	LS-156BSSD	Side-by-Side
mbm	MRN14B	Top Freezer
mbm	MRN14S	Top Freezer
mbm	MRN14W	Top Freezer
upstreman	BD116	Top Freezer
upstreman	BD116-Black	Top Freezer
upstreman	BD116-White	Top Freezer
upstreman	BD147	Top Freezer
upstreman	BD147-Black	Top Freezer
upstreman	BD147-White	Top Freezer
upstreman	BD176	Top Freezer
upstreman	BD176-Black	Top Freezer
upstreman	BD176-White	Top Freezer
upstreman	UF212	Freezerless and Single Door
upstreman	UF212-***	Freezerless and Single Door
“Danby” or “Danby Designer” or “Danby Diplomat”	DUF140A1WDB	Freezerless and Single Door

^The "*", "+", and "#" symbols on a model number serve as wildcard values and imply any character can be substituted in that space. One symbol equals one wildcard value.



A message from Entergy Mississippi, LLC ©2023 Entergy Services, LLC All Rights Reserved. The Entergy Solutions program is an energy efficiency program and not affiliated with Entergy Solutions, LLC. Authorized by the Mississippi Public Service Commission.